

حارقات الغاز



# NGX سلسيلة

دليل التركيب – الصيانة - الإستخدام

سيب أونيغاز

## <u>تحذيرات</u>

يتم توفير هذا الدليل كجزء لا يتجزأ وأساسيا للمنتج ويجب أن تسلم إلى المستخدم. المعلومات الواردة في هذا القسم هي مكرسة إلى كل من المستخدم وإلى العاملين المحترفين بعد التركيب والصيانة

و سوف يسهل البحث عن مزيد من المعلومات حول قيود التشغيل و الاستخدام، في القسم الثاني من هذا الدليل. ونحن نوصي بشدة لقراءته. احتفظ بهذا الدليل بعناية للمستقبل.

### الجزء الأول : التركيب

#### الميزات العامة

و نتميز هذه السلسلة من الحارقات بالعروض العالية والعرض في منحنيات الأداء، وعند الضغط في غرفة الاحتراق عالية. وتقدم أيضا مع غيرها من الميزات وظيفية هامة : هناك المقابس التي يمكن توصيلها بسهولة الى المرجل ، وإلى الكشف عن تحقيقات ، أحد المكونات الضغط في غرفة الاحتراق ، وتقام جميع المكونات الميكانيكية على طبق من ذهب التي يمكن اتخاذها بسرعة لإيقاف الصيانة. الرأس هو قابل للتعديل عن طريق برغي تخرج. يمكن تركيبه القطار الغاز إما على الجانب الأيمن أو على الحانب الأيسر



لوحة التحكم مع تبديل بدء التشغيل 1 رأس الاحتراق (بالداخل) 2 تشبت نظام الغاز 3 تشبت نظام الغاز 4 الغطاء 5 العطاء 5 العطاء 5 العطاء 5 العطاء 5 العطاء 6 المحرك (المزدوج المرحلة ، الشعلات التدريجية وتحوير بالكامل) 7 مناح ميور بالكامل) 7 مفتاح ضغط الهواء 9 مروحة المحرك 10 لوحة الشعلة 11 شفة 14

الغاز القادمة من خط العرض، يمر عبر مجموعة الصمامات المتوفرة مع التصفية والاستقرار. هذا يضن قواة واحدة للضغط في حدود الاستخدام. في المرحلة المزدوج، أو الشعلات التدريجية وتحوير بالكامل ، والمحرك الكهربائي (7) ، التي تتحرك نسبيا مثبط الهواء و صمامة الغاز ، يستخدم ضبط التكيف مع شكل متغير. هذا يسمح لتعظيم في سبل فصل بقدر منطقة الشعلة الاستفادة من قيم غاز المداخن ، والحصول على كفاءة الاحتراق. رأس الاحتراق (2) يحدد المواقع الإخراج الموقد. يتم توجيه الوقود (الغاز والبترول والغاز ، النفط الثقيل) في غرفة الاحتراق.

لوحة التحكم وضعت على جانب الأمامي للموقد ، وتظهر كل مرحلة التشغيل.

أنبوب النفخ 15

النوع	قوة المحرك ــ كوات
NGX35-NGX70	21-65
	35-150
NGX120-NGX200	
NGX280- NGX350	60-490
NGX400-NGX550	
LX60-LX65-LX72	165-1040
LX60-LX65-LX72	

مواصفات الشعلات

تحديد نمودج الحارق

.ويتم تحديد الشعلات حسب نوع وطراز الموقد. يوصف الشعلة تحديد النموذج على النحو التالي

طراز NG550 نوع	M PR.	S* A. 0. 50
(1)	(2)	(3) (4) (5) (6) (7) (8)
نمودج الحارق (1)		حارق ذو غاز طبيعي – NG
		LG - L.P.G. حارق
		NGX - Low NOx حارق
وقود (2)		غاز طبيعي – M
		L - LPG
العملية (3)		طابق مزدوج – AB طابق واحد – TN
		تحوير بالكامل – MD تجريجي - PR
أنبوب النفخ (4)		ممدد - L عادي - S
الدولة الموجه إليها (5)		أنضر لوحة البيانات
نسخة الحارق (6)		A - عادي
المعدات (7)		صمامات الغاز 2 = 0
		نضام تثبيت الغاز + صمامات الغاز 2 =1
		الحد الأقصى لتبديل ضغط الغاز + صمامات الغاز 2 = 7
		لحد الأقصى لتبديل + نضام تثبيت الغاز + صمامات الغاز 2 =8
ربط الغاز (8)		25 = Rp1 32 = Rp1"1/4 40 = Rp1"1/2

مستحنيات الأداع







للحصول على المداخلات بالكيلوكالوري في الساعة إضرب الكيلاوات في 860



Gas rate Stm<sup>3</sup>/h



	DN	A(S*)	A(L*)	B(S*)	B(L*)	С	±5mm	±5mm	F	G	н	J	κ	L	м	Ν	Omin	Omax	Р	Q	R	S	т	w	х	Y
NG/LG550	25/32	843	943	253	353	590	671	245	426	165	178	384	241	384	M10	247	157	192	174	552	377	175	69	543	533	155
NG/LG550	40	843	943	253	353	590	744	318	426	165	178	384	241	384	M10	247	157	192	174	552	377	175	69	553	533	155
NG/LG550	50	843	943	253	353	590	744	318	426	165	178	384	241	384	M10	247	157	192	174	552	377	175	69	603	533	155

حارقات طراز Low NOx حارقات طراز Low NOx ا



	DN	A(S*)	A(L*)	B(S*)	B(L*)	С	D ±5mm	E ±5mm	F	G	н	J	к	L	М	Ν	Omin	Omax	Ρ	Q	R	S	Т	w	Х	Y
NGX550	25/32	874	974	253	353	590	671	245	426	176	198	384	241	384	M10	247	157	192	174	552	377	175	69	543	533	168
NGX550	40	874	974	253	353	590	744	318	426	176	198	384	241	384	M10	247	157	192	174	552	377	175	69	553	533	168
NGX550	50	874	974	253	353	590	744	318	426	176	198	384	241	384	M10	247	157	192	174	552	377	175	69	603	533	168

## الوصلات الكهربائية

 $\triangle$ 

تحديد روابط التوصيل

مــصدر توصيل الموقد	<image/> The second seco
توصيل الشعلة عالية/منخفضة حارق تدريجي	ال رسم 16
توصيل مروحة المحرك	ال رسم 17

## هام : قبل تشغيل الموقد ، تأكد من ربط جميع الروابط كما هو موضح في المخططات





روابط الموقد التدريجي 🛛









### منحنيات الاحتراق ضغط رأس مقابل معدل تدفق الغاز





### المفتاح

- الـمولد 1
- منفذ الضغط على غرفة الاحتراق 2
- منفذ ضغط الغاز على صمام فراشة 3
- مقياس الضغط التفاضلي 4

### الجزء الثلي : العملية

### القيود المفروضة على الإستخدام

الـحارق هو جهاز صمم بالتدقيق لكي يعمل فقط بعد أن يتم ربطه بشكل صحيح مع مولد الحرارة (أومثال على المراجل ومولد هواء ساخن ، الفرن ، الخ) ، أي استخدام آخر يتعين غير سليم يعتبر بالتالي خطير.

### لسوحة مراقبة الشعلة





حـارقات طابق واحد \_ طابق مزدوج









D		01/	10/2008		_
Ρ		01		ა	4
		10	407	SFGUF	IOIALE
D	Ν	18 -	103	Э	Э

I LA/IIEM	FUNZI NE	FUN II N					
1	ΝΙΑΓΕΡΑ ΑΓΙΛΜΜΑ	L W FLAME TIME UNTER					
-	ΝΙΑ ΓΕ ΑLΙΑ ΓΙΑΜΜΑ						
C	ELEIIF D FILEVAZI NE FIAMMA	FLAME DETE THIN ELE TE DE					
EV1	ELEIIF VALV LE A ( FUFF VALV LE)	A ELE IF VALVE ( FVALVE FUF)					
ΓU1	FU IPILE LINEA M I FE VENTILAT FE	ΓΛΝΜΙΓΙΝΕΓUΕ					
ГU	LU INITE DI LINEA	LINE FU C					
ГU	LA INTER DI LINEA	LINE FU E					
ГU	Γυ ΙΡΙΔΕ Αυ ΙΔΙΑΓΙ	Λυχιμιλί γυ ε					
IL	INTELLINEA PLATILE	PUENEE LINE WILLII					
IM	INTELLINEA M T E VENTILAT LE	FANM I FLINE WIT II					
I M1 1	NIATI FEM I FEVENILAT FE						
LAF	LAMEADA Ε ΝΑLΑΖΙ ΝΕΑLΙΑ ΓΙΑΜΜΑΡΕΨΙΑΙ ΓΕ	PUENEE IN HEITELAME INDEATELIH					
LP	LAMEADA E NALAZI NEPL PEUTATE						
LPF	LAMEADA Ε ΝΑLΑΖΙ ΝΕΡΑ ΑΓΙΑΜΜΑΡΓΟ ΙΑΙ ΓΕ	PUFNEFIN LIW FLAME INDIALIFLIII					
LEV1	LΛΜΓΛDΛ Ε ΝΛLΛΖΙ ΝΕ ΛΓΕΓΙUΓΛ [EV1]	INDI A I F LI III F F ENIN FELE IF VALVE (EV1)					
LEV	LAMEADA E NALAZI NEAFEFIUEA [EV]	INDI A I F LI III F F ENIN FELE IF VALVE [EV]					
LL	LAMFADA E NALAZI NEFUNZI NAMENI PFUTAT FE	INDI A I E LI III PUENEE E EE A II N					
L	LAMFADA E NALAZI NEFEENZA A INFEIE	INDIATELIIIEFFEENE FA IN HIENEIW FI					
LIA	LAMFADA Ε ΝΑLΑΖΙΝΕΙΑ ΓΓΜΑΙΓΕDΙΑ ΕΝΙΝΕ	I NIII N IFAN F FMEFINDI AT FLITT					
LIA	LΛΜΓΛDΛ Ε ΝΛLΛΖΙ ΝΕΙ Λ Γ ΓΜΛΙ ΓΕ DΙΛ ΕΝ Ι ΝΕ	I NIII N IFAN F FMEFINDI AT F LI III					
MV	M I FE VENILAI FE	ΓΛΝΜΙΓ					
٢٨		MPU IIN AIF FFE UFE WILLI					
ſ		MINIMUM A FFE UFE WILLI					
ſ		MINIMUM A FFE UFE WILLI					
ſ		MINIMUM A FFE UFE WILLI					
٢	FUL ANTE PL FIAMMA	L I UIFE EIPUIIN					
F   100	NDA DI IEM EFATUFA	IEMFEFAIUFEFF PE					
ſ							
AIF NI DL 976	AFFAFE HIATUFA NIF LL FIAMMA	NIF L P X					
AIF NI DM 97	AFFAFE HIATUFA NIF LL FIAMMA	NIF LP X					
DILE	NDA DIFFE I NE	ווב חנבוו הב					
D IEMF	NDA DI IEM EFATUFA	IEMFEFAIUFEFF PE					
D 0 10V	IFA DULL FEULLAINTEN ENE	IFAN DU EF V LIA E UIFUI					
D 0 A	IFA DULL FEULLAIN FFENIE	IFAN DU EF UFFENT UTFUT					
IEMEN L P /LM /LME	AFFAFE HIATUFA NIF LL FIAMMA	NIF L P X					
IEMEN L P/LM /LME	AFFAFE HIATUFA NIF LL FIAMMA	NIF L P X					
IEMEN FWF ()	FE LAT FEM DULANIE	PUFNEF M DULAI F					
MA	ELETT LE WANNALE/ANT WAT	MANUAL/AUT MATE WITTE					
МГ	ELETT FE MANUALE FUNZI NAMENT MIN 0 MAX	MIN 0 MAX MANUAL FEFATI N WIT II					
N7	ELA WVND ELLVNDV VLIV (VLIELNVIIA)	AIF DAMFEF A TUAT F (ALTEFNATIVE)					
1		CLIC LINELW IVI LLLC MLC MILINE					
IA1 P0 6/ N 0L	ΕΓΥ ΜΛΝΟ ΕΓΓΛΝΟΛ ΛΓΙΛ	AIF DAMFEF A TUAT F					
1.0	ΙΓΛ Γ ΓΜΛΙ ΓΕ DIΛ ΕΝ Ι ΝΕ	I NIII N IFAN F FMEF					
IAP	ΙΕΓΜ ΙΛΙ /ΓΓΕ ΙΛΙ ΛΕΙΛ ΡΑ ΑΓΙΛΜΜΑ	III II L W IIIERM I A I/FFE UFE WILLIE					
1	IELW LLIV	IIIEFM UFLE					
1	IEFM INT /FFE INT DITUFEZZA	AFEI HIEFM IAI FIFE UFE WILH					
VF 50	NIF LL DITENUTA VALV LE A (FITNAL)	A FF VIN IEM (FII NAL)					

D	01/10/2008		
Ρ	01	4	Э
		SFGUF	IOIALE
D	N 18 – 163	1	Э



LV/ILEN د اے	FUNZIONE	FUN LICN
1	ΝΙΛ ΓΕΡΛ ΑΓΙΛΜΜΑ	L W FLAME TIME UNTER
L	ΝΙΛ ΓΕ ΛΙΙΛ ΓΙΛΜΜΛ	III II FLAME IIME UNIEF
ГU1	FU IPILE LINEA M I FE VENTILAT FE	FANM I FLINE FU E
ΓU	FU IPILE LINEA PFU IAT FE	PUINEI LINE FU E
IL	ΙΝΙΕΓΓUΙΙ ΓΕ LINEΛ ΡΓU ΙΛΙ ΓΕ	PUINEI LINE WII II
IM	INTELEVEN M T LE VENTILAT LE	FANM I FLINE WITTI
ΙΛΡ	FELE AU ILAFI	Λυχιμιλγ γ Γ ΕLΛΥ
LAF	LAMΓADA Ε ΝΑLΑΖΙ ΝΕΑLΙΑΓΙΑΜΜΑΡΓΟ ΙΑΙ ΓΕ	PUFNEF IN HEITELAME INDEATELIH
LP	LAMEADA E NALAZI NE PL - PEU IATE	INDIAI FLIIIFFPUFNEFL I UI
LPF	LAMFADA Ε ΝΑLΑΖΙ ΝΕΡΑ ΑΓΙΑΜΜΑΡΓΟ ΙΑΙ ΓΕ	PUFNEFIN L W FLAME INDI A I FLI III
I		EFIE FILIEFM IAL FFFE UFE WILLIE
ΙΛΡ	ΙΕΓΜ ΙΛΙ /ΓΓΕ ΙΛΙ ΑLΙΑ ΡΑ ΑΓΙΑΜΜΑ	III II L W IIIEFM I A I / FFE UFE WITTIE
1	IEFM INI /FFE INI DI IUFEZZN	AFEIY IIIEFM IAI FIFE UFE WILLI

SIGLA/ITEM	FUNZIONE	FUNCTION
C1	CONTAOPE BASSA ΓΙΑΜΜΑ	- ΙΕΤΙΝΚ ΙΛ-ΟΒ ΡΛΕΟΤΗ ΠΛ ΜΛΙΟΜ ΠΙΛΜΕΙΙΝ
C2	CONTΛΟΡΕ ΛLΤΛ ΓΙΛΜΜΛ	- ΙΕΤΙΝΚ ΙΛ-ΟΒ ΡΛΕΟΤΗ ΠΛ ΕΟΙΕΨΟΜ ΠΙΛΜΕΙΙΝ
ΓU1	FUSIBILE LINEA MOTOPE VENTILATOPE	ΙΙ ΙΛΒΙ ΙΙΙΙ ΠΙΙΙΙΟΣΙ ΛΙΙΙΙΤΙ ΙΒΙΙΙΙΙΙΙ ΙΒΙΙΙ ΛΤΙ ΙΙ ΒΙ ΙΙΤΙΙΙ ΙΤΟΡΛ
ГИЗ	FUSIBILE LINEA BPUCIATOPE	ΠΙΛΒΚΝΗ ΠΡΕΙΟΣΡΛΙΙΝΤΕΙΕ ΙΝΙΙΝΗ ΓΟΡΕΙΚΗ
IL	INTEPPUTTOPE LINEA BPUCIATOPE	ΒΙΙΚ ΙΦΙΛΤΕΙΚ ΙΝΙΙΝΝ ΓΟΡΕΙΚΝ
IM	INTEPPUTTOPE LINEA MOTOPE VENTILATOPE	ΒΙΙΚ ΙΝ ΙΛΤΕ ΙΚ ΙΝΙΙΝΝ ΔΒΝΓΛΤΕ ΙΙ ΒΕΙΙΤΝ Ι ΙΤΟΡΛ
КVВ	PELE AUSILIAPIO	B NOMOFATE INHOE PE IE
LAF	LAMPADA SEGNALAZIONE ALTA ΓΙΑΜΜΑ ΒΡυCΙΑΤΟΡΕ	ΝΓΙΙΛΙΒΙΙΛΙΙΛΜΠΟΙΚΛ ΒΟΙΒЩΟΓΟ ΠΙΛΜΕΙΙΝ ΓΟΡΕΙΚΝ
LB	LAMPADA SEGNALAZIONE BLOCCO BPUCIATOPE	-ΝΓΙΙΛΙΒΙΙΛΙΙΛΜΠΟΙΚΛ ΕΙΟΚΝΡΟΒΚΝ ΓΟΡΕΙΚΝ
LBL	LAMPADA SEGNALAZIONE BASSA FIAMMA BPUCIATOPE	- ΜΓΙΙΛ ΙΒΙΙΛ Ι ΙΛΜΠΟΙΚΛ ΜΛΙΟΓΟ ΠΙΛΜΕΙΙΝ ΓΟΡΕΙΚΝ
ST	SEPIE TEPMOSTATI/PPESSOSTATI	ΡΙΙ ΤΕΡΜΟ-ΤΛΤΟΒ/ΡΕΙΕ ΙΛΒΙΕΙΙΝΙ
ТЛВ	TEPMOSTATO/PPESSOSTATO ALTA-BASSA FIAMMA	ΤΙ ΡΜΟ ΤΛΤ/ΡΙ ΙΙ ΔΛΒΙΙ ΙΙΙΙ ΙΟ ΙΕΨΟΓΟ/ΜΑΙΟΓΟ ΠΙΛΜΙ ΙΙΙΙ
TS	TEPMOSTATO/PPESSOSTATO DI SICUPEZZA	ΠΡΕΙΟΣΡΛΙΙΝΤΕ ΙΒΙΙΙΙΝ ΤΕΡΜΟ-ΤΛΤ/ ΡΕ ΙΕ ΙΛΒΙΕΙΙΝΙ

D		26/06/2008	РРГС <b>1</b>	
Ρ		00	1	Ζ
		<b>TID</b> 4	SLCAL	ΙΟΙΛΙΓ
D	N	IVB_1	/	1

## الستذييسل







رسم التوصيلات LME21







### توصيات هامة لاستعمال الجهاز بكل أمان

مقدمة : إن الهدف من هذه التوصيات هو المساهمة خلال عملية الاستعمال، في حماية المكونات بالنسبة لتركيب السخان ذو الاستعمال المنزلي و توفير الماء الساخن للاستعمال الصحي، مع بيان التصرفات المناسبة و الواجب اتخادها لتفاجي الاخلال بخصائص الأمان الأصلية عن طريق احتمال تركيب خاطئ للجهاز، استعمل غير مناسب أو غير عقلاني. إن الهدف من نشر هذه التوصيات أيضا هو تحسيس جمهور المستعملين بمشاكل الأمان عن طريق لغة ضروري أن تكون تقنية لكن في متناول الجميع. إن المنتج يرفض تحمل أي مسؤولية تعاقدية أو غير متقاعدة في حالة الأضرار التي تتسبب فيها الأخطاء المرتكبة خلال التركيب أو الإستعمال و في كل الحالات بعدم احترام التوصيات المقدمة من طرف المنتح.

### توصيات عامة

- إن دليل المستخدم جزء أساسي لا يتجزأ من المنتوج يجب تقديمه إلى المستعمل. اقرأ جيدا التوصيات الواردة في الدليل لاحتوائها على معلومات هامة بخصوص التركيب، الاستعمال و الصيانة الآمنة. احتفظ جيدا بدليل الإستعمال لاحتمال الحاجه اليه لاحقا.
- يجب تركيب الجهاز طبقا للمعايير المعمول بها، حسب تعليمات المنتج و من طرف احترافيين مؤهلين مهنيا. نعني بالأشخاص المهنيين، الاشخاص المتمتعين بالكفاءات التقنية الازمة في ميدان أجزاء السخان ذو الإستعمال الخاص و التزويد بالماء الساخن ذو الإستعمال الصحي و بصفة خاصة مراكز خدمات ما بعد البيع المعتمدة من طرف المنتج. التركيب الغير المناسب قد يتسبب في أضرار للإنسان و الحيوان يتجرد البائع من تحمل أي مسؤولية.
- بعد إزالة كاملة الأغلفة، تأكد من حالة المحتوى، في حالة شك لا تستعمل الجهاز و اتصل بالممون.

عناصر التعليب (قفص من خشب، مسامير، مساسيك، بلاستيك، الخ) لا تترك في متناول الأطفال لتشكيلها خطر عليهم.

- قبل الشروع في أي عملية تنضيف أو صيانة، اعزل الجهاز عن شبكة التزيد باستعمال القاطع أو أجهزة القطع الملائمة.
- في حالة عطب أو سوء استعمال الجهاز، اعزله و لا تقع باي محاولة تصليح أو تدخل مباشر. يجب اللجوء فقط لمهنيين مؤ هلين. عملية تصليح الأجزاء المحتملة يجب أن تكون في مراكز خدمات ما بعد البيع لشركة سيماكس باستعمال قطع غيار أصلية فقط. عدم التقيد بهذا الإجراء قد يخ بأمان الجهاز. لضمان مردود فعال، يستحسن القيام يعمليات صيانة دورية من طرف أشخاص مأهلين مع احترام تعليمات المنتج.
- في حالة بيع أو نقل الجهاز، و في حالة رحيل المالك و ترك الجهاز يعمل، يجب التأكد من مرافقة دليل الاستخدام للجهاز حتى يتمكن من تشغيله أو تركيبه.

### شروط تطبيق الضمان :

لا يتم تطبيق هذا الضمان إلا في حالة ما اذا تم تقديم المنتج الذي به جلل مدة الضمان مرفقا بفاتورة الشراء. كما تحتفظ شركة سيماكس في حقها في أن ترفض التطبيق المجاني للضمان إذا لم يتم تقديم هذه الوثائق أو إذا كانت غير واضحة أو غير مكتملة. في كل الأحوال فإن الزبون النهائي سوف يتم مطالبته بتقديم الفاتورة المتضمنة لكل المعلومات عن طبيعة المنتج و تاريخ الشراء و غيره من المعلومات المذكورة في القصاصة المرفقة للفاتورة.

من إنتاج شركة "سيب أونيغاز إيطاليا +39 049 9200944: هاتف فاكس: +39 049 9200945



C.I.B. UNIGAS S.p.A. Via L.Galvani, 9 - 35011 Campodarsego (PD) - ITALY Tel. +39 049 9200944 - Fax +39 049 9200945/9201269 web site: www.cibunigas.it - e-mail: cibunigas@cibunigas.it



## **CIB UNIGAS 600V**

CONTROLLER



## **USER'S MANUAL**

COD. M12925CA Rel 1.2 08/2014

SOFTWARE VERSION 1.0x T73 code 80379 / Edition 01 - 06/2012

## **1 · INSTALLATION**

### · Dimensions and cut-out; panel mounting





70

#### Panel mounting:

To fix the unit, insert the brackets provided into the seats on either side of the case. To mount two or more units side by side, respect the cut-out dimensions shown in the drawing.

CE MARKING: The instrument conforms to the European Directives 2004/108/CE and 2006/95/CE with reference to the generic standards: EN 61000-6-2 (immunity in industrial environment) EN 61000-6-3 (emission in residential environment) EN 61010-1 (safety).

MAINTENANCE: Repairs must be done only by trained and specialized personnel.

Cut power to the device before accessing internal parts.

Do not clean the case with hydrocarbon-based solvents (Petrol, Trichlorethylene, etc.). Use of these solvents can reduce the mechanical reliability of the device. Use a cloth dampened in ethyl alcohol or water to clean the external plastic case.

SERVICE: GEFRAN has a service department. The warranty excludes defects caused by any use not conforming to these instructions.

#### EMC conformity has been tested with the following connections

FUNCTION	CABLE TYPE	LENGTH
Power supply cable	1 mm <sup>2</sup>	1 m
Relay output cable	1 mm <sup>2</sup>	3,5 m
TC input	0,8 mm <sup>2</sup> compensated	5 m
Pt100 input	1 mm <sup>2</sup>	3 m

### 2 · TECHNICAL SPECIFICATIONS

Display	2x4 digit green, high display 10 and 7mm
Keys	4 of mechanical type (Man/Aut, INC, DEC, F)
Accuracy	0.2% f.s. ±1 digit ambient temperature 25°C
Main input (settable digital filter)	TC, RTD, PTC, NTC 60mV,1V Ri≥1MΩ; 5V,10V Ri≥10KΩ; 20mA Ri=50Ω Tempo di campionamento 120 msec.
Type TC Thermocouples (ITS90)	Type TC Thermocouples : J,K,R,S,T (IEC 584-1, CEI EN 60584-1, 60584-2); custom linearization is available / types B,E,N,L GOST,U,G,D,C are available by using the custom linearization.
Cold junction error	0,1° / °C
RTD type (scale configurable within indicated range, with or without decimal point) (ITS90)	DIN 43760 (Pt100), JPT100 20Ω
PTC type / NTC Type	9900 25°C / 1KO 25°C
Safety	detection of short-circuit or opening of probes, LBA alarm
°C / °F selection	configurable from faceplate
Linear scale ranges	-1999 to 9999 with configurable decimal point position
Controls	PID, Self-tuning, on-off
pb - dt - it	0,0999,9 % - 0,0099,99 min - 0,0099,99 min
Action	Heat / Cool
Control outputs	on / off
Maximum power limit heat / cool	0,0100,0 %
Cycle time	0200 sec
Main output type	relay, logic, continuous (010V Rload $\ge$ 250K $\Omega$ , 0/420mA Rload $\le$ 500 $\Omega$ )
Softstart	0,0500,0 min
Fault power setting	-100,0100,0 %
Automatic blanking	Displays PV value, optional exclusion
Configurable alarms	Up to 3 alarm functions assignable to an output, configurable as: maximum, minimum, symmetrical, absolute/deviation, LBA
Alarm masking	<ul> <li>exclusion during warm up</li> <li>latching reset from faceplate or external contact</li> </ul>
Type of relay contact	NO (NC), 5A, 250V/30Vdc cosφ=1
Logic output for static relays	24V ±10% (10V min at 20mA)
Transmitter power supply	15/24Vdc, max 30mA short-circuit protection
Power supply (switching type)	(std) 100 240Vac ±10% (opt.) 1127Vac/dc ±10%; 50/60Hz, 8VA max
Faceplate protection	IP65
Working / Storage temperature range	050°C / -2070°C
Relative humidity	20 85% non-condensing
Environmental conditions of use	for internal use only, altitude up to 2000m
Installation	Panel, plug-in from front
Weight	160g for the complete version
l	



## **5** • "EASY" PROGRAMMING and CONFIGURATION



#### • Prot



12

### 6 • PROGRAMMING and CONFIGURATION



N.B.: Once a particular configuration is entered, all unnecessary parameters are no longer displayed

### InFo Display



• CFG

	CFG	Con	trol para	ameters		
						0 1 1 1
0	CL.	Enabling	S.tun	autotuning	Sel-ttuning	Softstart
	コニロ	self-tuning,	0	NU	NO	NO
		autotuning,	1	YES NO	NU	NO
		softstart	- 2	VES	VES	NO
				NO	NO	VES
			5	YES	NO	YES
			6	-	-	-
			7	-	-	-
			Stup	Autotuning	Solftuning	Softetart
			0.tun	one shot	Senturning	Sonsian
			8*	WAIT	NO	NO
			9	GO	NO	NO
			10*	WAIT	YES	NO
			11	GO	YES	NO
			12*	WAIT	NO	YES
			13	GO	NO	YES
	, ,	+32 with passa +64 with passa +128 with passa	age auto age auto age auto	omatic rifle in Comatic rifle in Comatic rifle in Comatic rifle in Comatic rifle in C	GO if PV-SP GO if PV-SP GO if PV-SP	> 1% > 2% > 4%
1.2	h.₽b ↓	Proportional heating or hys regulation C	band foi teresis i N/OFF	0 99	9.9% f.s.	
5.83	h. IE	Integral time for heating 0.00 99.99 min				
	↓					
1.33	hdt	Derivative time for heating 0.00 99.99 min		99.99 min		
				_		
100.0	hPH	Maximum power limit for 0.0 100.0		100.0%		
	<b>\</b>			_		
0.0	hPL	Minimum pov for heat (not available for o cool action	wer limit ing double he on)	at/	100.0%	
	*	L				







For custom linearization:

0...60 mV

12...60 mV

12...60 mV

0...20 mA 0...20 mA

4...20 mA

4...20 mA

0...10 V

0...10 V

2...10 V

2...10 V 0...5 V

0...5 V 1...5 V 1...5 V

0...1 V

0...1 V

200mv..1V

200mv..1V Cust10 V-20mA

Cust10 V-20mA

Cust 60mV

Cust 60mV

PT100-JPT

PTC

NTC

39

40

41

42

43

44

45

46

47

48

49

50

51 52

53

54

55

56

57

58

59

60

61

62 63

64

- LO signal is generated with variable below Lo.S or at minimum calibration value

Custom scale

-1999/9999

Custom scale

CUSTOM

CUSTOM

CUSTOM

Custom scale

-199.9/999.9

Custom scale

-199.9/999.9 Custom scale

-199.9/999.9

Custom scale

-199.9/999.9

Custom scale

-199.9/999.9

Custom scale

-199.9/999.9

Custom scale -199.9/999.9

Custom scale

-199.9/999.9

Custom scale

-199.9/999.9

Custom scale

-199.9/999.9

Custom scale

-199.9/999.9

Custom scale

CUSTOM

CUSTOM

CUSTOM

- HI signal is generated with variable above Lo.S or at maximum calibration value

• Out



### • Prot

12

#### Pro Protection code Prot Display Modification SP, Hy.P, Hy.n, AL.2, AL.3, PoS, OuP, INF SP, Hy.P , Hy.n, AL.2, AL.3, PoS 0 1 SP, Hy.P, Hy.n, AL.2, AL.3, PoS, OuP, INF SP 2 SP, OuP, INF + 4 to disable InP, Out + 8 to disable CFG + 8 to disable Grog + 16 to disable SW "power-up - power down" + 32 disable manual power latching + 64 to disable manual power modification

+128 enables full configuration

Note: OuP and INF only display configuration extended

### • Hrd





## • Lin



## • U.CAL



### 7 · CONSENT FOR BURNER AL1



Obtain burner consent by configuring alarm 1 as inverse deviation with positive hysteresis Hy.P and negative hysteresis Hy.n

### 8 • PRE-HEATING FUNCTION

Enable the pre-heating function by setting parameters GS.0, Ht.0, GS.1 other than zero.

It consists of three phases that are activated sequentially at firing:

- Ramp 0 phase

Enabled by setting GS.0 > 0. Starting from setpoint = PV (initial state), it reaches pre-heating set SP.0 with gradient GS.0 - Maintenance phase

- Enabled by setting Ht.0 > 0. Maintains pre-heating setpoint SP.0 for time Ht.0
- Ramp 1 phase

Enabled by setting GS.1 > 0. Starting from pre-heating setpoint SP.0, it reaches active \_SP set with gradient GS.1

In case of selftuning, the pre-heating function is not activated



### 9 · ADJUSTMENT WITH MOTORIZED VALVE

In an adjustment process the adjustment valve has the function of varying fuel delivery (frequently corresponding to the thermal energy introduced into the process) in relation to the signal coming from the controller.

For this purpose it is provided with an actuator able to modify its opening value, overcoming the resistances produced by the fluid passing inside it.

The adjustment valves vary the delivery in a modulated manner, producing finite variations in the fluid passage inner area corresponding to finite variations of the actuator input signal, coming from the controller. The servomechanism, for example, comprises an electric motor, a reducer and a mechanical transmission system which actions the valve.

Various auxiliary components can be present such as the mechanical and electrical safety end travels, manual actioning systems.



CONTROL EXAMPLE FOR V0 VALVE

The controller determines, on the basis of the dynamics of the process, the control output for the valve corresponding to the opening of the same in such a way so as to maintain the desired value of the process variable.

#### Characteristic parameters for valves control

- Actuator time (Ac.t) is the time employed by the valve to pass from entirely open to entirely closed (or vice-versa), and can be set with a resolution of one second. It is a mechanical feature of the valve+actuator unit.

NOTE: if the actuator's travel is mechanically limited it is necessary to proportionally reduce the Ac.t value.

- Minimum impulse (t.Lo) expressed as a % of the actuator time (resolution 0.1%).

Represents the minimum change in position corresponding to a minimum change in power supplied by the instrument below which the actuator will not physically respond to the command.

This represents the minimum variation in position due to which the actuator does not physically respond to the command.

The minimum duration of the movement can be set in t.Lo, expressed as a % of actuator time.

- Impulsive intervention threshold (t.Hi) expressed as a % of the actuator time (resolution 0.1%) represents the position displacement (requested position – real position) due to which the manoeuvre request becomes impulsive.

You can choose between 2 types of control:

1) ON time of movement = t.on and OFF time proportional to shift and greater than or equal to t.Lo (we recommend setting t.on = t.Lo) (set t.oF = 0).

2) ON time of movement = t.on and OFF time = t.oF. A value set for t.oF < t.on is forced to t.on. To activate this type, set t.oF <> 0.

The type of movement approach allows fine control of the reverse drive valve (from potentiometer or not), especially useful in cases of high mechanical inertia. Set t.Hi = 0 to exclude modulation in positioning.

This type of modulated approach allows precise control of the feedback actioned valve, by a potentiometer or not, and is especially useful in cases of high mechanical inertia. Setting t.Hi = 0 excludes modulation in positioning.

- Dead zone(dE.b) is a displacement band between the adjustment setpoint and the process variable within which the controller does not supply any command to the valve (Open = OFF; Close = OFF). It is expressed as a percentage of the bottom scale and is positioned below the setpoint. The dead zone is useful in an operative process to avoid straining the actuator with repeated commands and an insignificant effect on the adjustment. Setting dE.b = 0 the dead zone is excluded.



Graph of behavior inside the band with integral time  $\neq 0$ .

With integral time = 0, movement ON time is always equal to OFF time.

t0 = t.Lo

### Valve control modes

With the controller in manual, the setting of parameter At.y ≥ 8 allows direct control of the valve open and close commands through the keyboard Increments and Decrements on the front seats.

#### V0 - for floating valve without potentiometer

Model V0 have similar behaviour: every manoeuvre request greater than the minimum impulse t.Lo is sent to the actuator by means of the OPEN/CLOSE relays; every action updates the presumed position of the virtual potentiometer calculated on the basis of the actuator travel declared time. In this way there is always a presumed position of the valve which is compared with the position request of the controller.

Having reached a presumed extreme position (entirely open or entirely closed determined by the "virtual potentiometer") the controller provides a command in the same direction, in this way ensuring the real extreme position is reached (minimum command time = t.on).

The actuators are usually protected against the OPEN command in the entirely open position or CLOSE command in the entirely closed position.

#### V3 - for floating valve, PI control

When the difference between the position calculated by the controller and the only proportional component exceeds the value corresponding to the minimum impulse t.Lo the controller provides an OPEN or CLOSE command of the duration of the minimum impulse itself t.Lo. At each delivery the integral component of the command is set to zero (discharge of the integral).

The frequency and duration of the impulses is correlated to the integral time (h.it or c.it).

#### Non-movement behavior

t.Hi = 0: with power = 100% or 0.0%, the corresponding open or close outputs always remain enabled (safety status).

#### Movement behavior

t.Hi <> 0: with position attained corresponding to 100% or 0.0%, the corresponding open or close outputs are switched off.



If t.oF = 0, current function is maintained.

If t.oF  $\neq$  0 movement mode will be as shown on the graph

### **10 · CONTROL ACTIONS**

Proportional Action:

action in which contribution to output is proportional to deviation at input (deviation = difference between controlled variable and setpoint). *Derivative Action*:

action in which contribution to output is proportional to rate of variation input deviation. Integral Action:

Integral Action.

action in which contribution to output is proportional to integral of time of input deviation.

#### Influence of Proportional, Derivative and Integral actions on response of process under control

\* An increase in P.B. reduces oscillations but increases deviation.

\* A reduction in P.B. reduces the deviation but provokes oscillations of the controlled variable (the system tends to be unstable if P.B. value is too low).

\* An increase in Derivative Action corresponds to an increase in Derivative Time, reduces deviation and prevents oscillation up to a critical value of Derivative Time, beyond which deviation increases and prolonged oscillations occur.

\* An increase in Integral Action corresponds to a reduction in Integral Time, and tends to eliminate deviation between the controlled variable and the setpoint when the system is running at rated speed.

If the Integral Time value is too long (Weak integral action), deviation between the controlled variable and the setpoint may persist.

Contact GEFRAN for more information on control actions.

## 11 • MANUAL TUNING

#### A) Enter the setpoint at its working value.

B) Set the proportional band at 0.1% (with on-off type setting).

C) Switch to automatic and observe the behavior of the variable. It will be similar to that in the figure:



D) The PID parameters are calculated s follows: Proportional band

#### Peak P.B.= ----- x 100 (V max - V min)

(V max - V min) is the scale range.

Integral time: It = 1.5 x T

Derivative time: dt = It/4

E) Switch the unit to manual, set the calculated parameters. Return to PID action by setting the appropriate relay output cycle time, and switch back to Automatic. F) If possible, to optimize parameters, change the setpoint and check temporary response. If an oscillation persists, increase the proportional band. If the response is too slow, reduce it.

## 12 · SET GRADIENT

SET GRADIENT: if set to ≠0, the setpoint is assumed equal to PV at power-on and auto/man switchover. With gradient set, it reaches the local setpoint. Every variation in setpoint is subject to a gradient.

The set gradient is inhibited at power-on when self-tuning is engaged.

If the set gradient is set to  $\neq 0$ , it is active even with variations of the local setpoint.

The control setpoint reaches the set value at the speed defined by the gradient.

## 13 · SOFTWARE ON / OFF SWITCHING FUNCTION

How to switch the unit OFF: hold down the "F" and "Raise" keys simultaneously for 5 seconds to deactivate the unit, which will go to the OFF state while keeping the line supply connected and keeping the process value displayed. The SV display is OFF.

All outputs (alarms and controls) are OFF (logic level 0, relays de-energized) and all unit functions are disabled except the switch-on function and digital communication.

How to switch the unit ON: hold down the "F" key for 5 seconds and the unit will switch OFF to ON. If there is a power failure during the OFF state, the unit will remain in OFF state at the next power-up (ON/OFF state is memorized).

The function is normally enabled, but can be disabled by setting the parameter Prot = Prot +16.

## 14 · SELF-TUNING

The function works for single output systems (heating or cooling). The self-tuning action calculates optimum control parameter values during process startup. The variable (for example, temperature) must be that assumed at zero power (room temperature).

The controller supplies maximum power until an intermediate value between starting value and setpoint is reached, after which it zeros power.

PID parameters are calculated by measuring overshoot and the time needed to reach peak. When calculations are finished, the system disables automatically and the control proceeds until the setpoint is reached.

#### How to activate self-tuning:

- A. Activation at power-on
- 1. Set the setpoint to the required value
- 2. Enable selftuning by setting the Stun parameter to 2 (CFG menu)
- 3. Turn off the instrument
- 4. Make sure the temperature is near room temperature
- 5. Turn on the instrument again
- B. Activation from keyboard
- 1. Make sure that key M/A is enabled for Start/Stop selftuning (code but = 6 Hrd menu)
- 2. Bring the temperature near room temperature
- 3. Set the setpoint to the required value
- 4. Press key M/A to activate selftuning (Attention: selftuning interrupts if the key is pressed again)

The procedure runs automatically until finished, when the new PID parameters are stored: proportional band, integral and derivative times calculated for the active action (heating or cooling). In case of double action (heating or cooling), parameters for the opposite action are calculated by maintaining the initial ratio between parameters (ex.: CPb = HPb \* K; where K = CPb / HPb when self-tuning starts). When finished, the Stun code is automatically cancelled.

#### Notes :

-The procedure does not start if the temperature is higher than the setpoint (heating control mode) or if the temperature is lower than the setpoint (cooling control mode). In this case, the Stu code is not cancelled.

-It is advisable to eneable one of the configurable LEDs to signal selftuning status.By setting one of parameters

LED1, LED2, LED3=4 or 20 on the Hrd menu, the respective LED will be on or flashing when selftuning is active.



## 15 · ACCESSORIES

### Interface for instrument configuration





### WARNINGS

WARNING: this symbol indicates danger. It is placed near the power supply circuit and near high-voltage relay contacts.

Read the following warnings before installing, connecting or using the device:

· follow instructions precisely when connecting the device.

· always use cables that are suitable for the voltage and current levels indicated in the technical specifications.

• the device has no ON/OFF switch: it switches on immediately when power is turned on. For safety reasons, devices permanently connected to the power supply require a twophase disconnecting switch with proper marking. Such switch must be located near the device and must be easily reachable by the user. A single switch can control several units.

• if the device is connected to electrically NON-ISOLATED equipment (e.g. thermocouples), a grounding wire must be applied to assure that this connection is not made directly through the machine structure.

• if the device is used in applications where there is risk of injury to persons and/or damage to machines or materials, it MUST be used with auxiliary alarm units. You should be able to check the correct operation of such units during normal operation of the device.

• before using the device, the user must check that all device parameters are correctly set in order to avoid injury to persons and/or damage to property.

• the device must NOT be used in infiammable or explosive environments. It may be connected to units operating in such environments only by means of suitable interfaces in conformity to local safety regulations.

• the device contains components that are sensitive to static electrical discharges. Therefore, take appropriate precautions when handling electronic circuit boards in order to prevent permanent damage to these components.

Installation: installation category II, pollution level 2, double isolation

The equipment is intended for permanent indoor installations within their own enclosure or panel mounted enclosing the rear housing and exposed terminals on the back.

• only for low power supply: supply from Class 2 or low voltage limited energy source

• power supply lines must be separated from device input and output lines; always check that the supply voltage matches the voltage indicated on the device label.

• install the instrumentation separately from the relays and power switching devices

• do not install high-power remote switches, contactors, relays, thyristor power units (particularly if "phase angle" type), motors, etc... in the same cabinet.

· avoid dust, humidity, corrosive gases and heat sources.

· do not close the ventilation holes; working temperature must be in the range of 0...50°C.

surrounding air: 50°C

• use 60/75°C copper (Cu) conductor only, wire size range 2x No 22 - 14AWG, Solid/Stranded

• use terminal tightening torque 0.5N m

If the device has faston terminals, they must be protected and isolated; if the device has screw terminals, wires should be attached at least in pairs.

• Power: supplied from a disconnecting switch with fuse for the device section; path of wires from switch to devices should be as straight as possible; the same supply should not be used to power relays, contactors, solenoid valves, etc.; if the voltage waveform is strongly distorted by thyristor switching units or by electric motors, it is recommended that an isolation transformer be used only for the devices, connecting the screen to ground; it is important for the electrical system to have a good ground connection; voltage between neutral and ground must not exceed 1V and resistance must be less than 60hm; if the supply voltage is highly variable, use a voltage stabilizer for the device; use line filters in the vicinity of high frequency generators or arc welders; power supply lines must be separated from device input and output lines; always check that the supply voltage matches the voltage indicated on the device label.

• Input and output connections: external connected circuits must have double insulation; to connect analog inputs (TC, RTD) you have to: physically separate input wiring from power supply wiring, from output wiring, and from power connections; use twisted and screened cables, with screen connected to ground at only one point; to connect adjustment and alarm outputs (contactors, solenoid valves, motors, fans, etc.), install RC groups (resistor and capacitor in series) in parallel with inductive loads that work in AC (*Note: all capacitors must conform to VDE standards (class x2) and support at least 220 VAC. Resistors must be at least 2W*); fit a 1N4007 diode in parallel with the coil of inductive loads that operate in DC.

GEFRAN spa will not be held liable for any injury to persons and/or damage to property deriving from tampering, from any incorrect or erroneous use, or from any use not conforming to the device specifications.

### Set-up for 600V RRR0-1-T73 regulator

### Set up for temperature probe Pt100 (ex Siemens QAE2120 130°C max.)

# The regulator comes out of the factory preset with the corresponding values of the Siemens RWF40.000 and RWF50.2x

### Verify wiring of the sensor



Regulation of the set-point **= 80** It can be modified by using arrows "up" and "down". By pushing **F** you go to parameters:

Hy.P	5 (hysteresis positive for output 1, terminals 21-22 (ex Q13-Q14)
Hy.n	-5 hysteresis negative for output ,1 terminals 21-22 (ex Q13-Q14)

Keep pushing F until you see PASS, release F and through the arrows set 99, push F and visualize Pro (protection code) default is 12, through the arrows set 128 and push F, keep it pushed until all parameters InF, CFG, InP, Out, PASS are visualized.

CFG	
S.tun	0
hPb	1,2
hlt	5,83
hdt	1,33

InP					
tyP	30 (Pt100)				
dP_S	1 (decimals num.)				
Lo.S	0 (min. sensor scale)				
Hi.S	850,0 (max sensor scale)				
oFS	0 (offset of input correction)				
Lo.L	30,0 (lower set-point range limit)				
Hi.L	130,0 (upper set-point range limit)				
Out					
------	--------------------------------------------------	--	--	--	--
A1.r	0				
A1.t	3 (operating mode AL1 =inverse-relative-normal)				
rL.1	2 (AL1)				
rL.2	18 (open)				
rL.3	19 (close)				
rEL	0				
A.ty	9 (type of servocontrol command)				
Ac.t	12 (servocontrol running time: SQN72.4/STA12=12;				
	SQM40.265=30)				
t_Lo	2				
t_Hi	0.0				
t.on	2				
t.oF	0.0				
dE.b	0,1 (dead zone in % of end scale)				

PAS	99 then push and keep pushed <b>F</b> until visualization of <b>Hrd</b>				
Hrd					
CtrL	6 (PID warm)				
AL.nr	1				
but	1				
diSP	0				
Ld.1	1				
Ld.2	28				
Ld.3	20				

Keep pushed F until you visualize **PASS**, release F and through the arrows set **99**, push F and visualize **Pro** (protection code) from **128**, through the arrows, bring it back to **12**, and keep F pushed until you come back to set-point value.

### Manual operation :

Keep pushed the lower left key for at least 5 sec.

The instrument will enter the "MAN" mode (see also "Ld1" switching on).

Through the arrows, "Open" and "Close" outputs are activated.

To come back to normal working keep the lower left key pushed for at least 5 sec.

### Software switch off :

By keeping pushed keys **Arrow up** + **F** for more than 5 sec. the instrument switches off the software, does not command the outputs and visualize only the variable of process measured by the probe. To restore keep pushed **F** for more than 5 sec.

### Set up for temperature probe Pt100 for high temperature (350°C max.)

### Verify wiring of the sensor



### Regulation of the set-point = 80

It can be modified by using arrows "up" and "down".

By pushing <b>F</b> you go to parameters:	
Hy.P	10 (hysteresis positive for output 1 terminals 21-22 (ex Q13-Q14)
Hy.n	-5 (hysteresis negative for output 1 terminals 21-22 (ex Q13-Q14)

Keep pushing F until you see PASS, release F and through the arrows set 99, push F and visualize Pro (protection code) default is 12, through the arrows set 128 and push F, keep it pushed until all parameters InF, CFG, InP, Out, PASS are visualized.

CFG	
S.tun	0
hPb	1,2
hlt	5,83
hdt	1,33

InP	
tyP	30 (Pt100)
dP_S	1 (decimals num.)
Lo.S	0 (min. sensor scale)
Hi.S	850,0 (max sensor scale)
oFS	0 (offset of input correction)
Lo.L	0,0 (lower set-point range limit)
Hi.L	350,0 (upper set-point range limit)

Out					
A1.r	0				
A1.t	3 (mode AL1 =inverse-relative-normal)				
rL.1	2 (AL1)				
rL.2	18 (open)				
rL.3	19 (close)				
rEL	0				
A.ty	9 (type of servocontrol command)				
Ac.t	12 (servocontrol running time: SQN72.4/STA12=12; SQM40.265=30)				
t_Lo	2				
t_Hi	0.0				
t.on	2				
t.oF	0.0				
dE.b	0,1 (dead zone in % of end scale)				

PAS	99 then push and keep pushed F until visualization of Hrd				
Hrd					
CtrL	6 (PID warm)				
AL.nr	1				
but	1				
diSP	0				
Ld.1	1				
Ld.2	28				
Ld.3	20				

Keep pushed F until you visualize PASS, release F and through the arrows set 99, push F and visualize Pro (protection code) from 128, through the arrows, bring it back to 12, and keep F pushed until you come back to set-point value.

### Manual operation:

Keep pushed the lower left key for at least 5 sec.

The instrument will enter the "MAN" mode (see also "Ld1" switching on). Through the arrows, "Open" and "Close" outputs are activated.

To come back to normal working keep the lower left key pushed for at least 5 sec.

### Software switch off :

By keeping pushed keys Arrow up + F for more than 5 sec. the instrument switches off the software, does not command the outputs and visualize only the variable of process measured by the probe. To restore keep pushed **F** for more than 5 sec.

### Set up for pressure transmitter 2 wires signal 4+20mA



With pressure transmitters first we need to enable their power supply: remove the part as shown below, then, on the CPU unit, move the bridge from Pt100 to +Vt



### Verify wiring of the sensor

### Impostazione set-point

Transmitter	1,6bar	3bar	10bar	16bar	25bar	40bar
Set-point	1bar	1,5bar	6bar	6bar	6bar	6bar

To modify it directly use "up" and "down" arrows.

By pushing <b>F</b> you go to parameter:							
Transmitter	1,6bar	3bar	10bar	16bar	25bar	40bar	
Hy.P	0,2bar	0,5bar	0,5bar	0,8bar	1,25bar	2bar	
Hy.n	0bar	0bar	0bar	0bar	0bar	0bar	

Keep pushing **F** until you see **PASS**, release **F** and through the arrows set **99**, push **F** and visualize **Pro** (protection code) default is **12**, through the arrows set **128** and push **F**, keep it pushed until all parameters **InF**, **CFG**, **InP**, **Out**, **PASS** are visualized.

CFG	
S.tun	0
hPb	5
hlt	1,33
hdt	0,33

InP	
tyP	44 (4÷20mA)
dP_S	2 (decimals num.)

Transmitter	1,6bar	3bar	10bar	16bar	25bar	40bar		
Lo.S	0,00	0,00	0,00	0,00	0,00	0,00	min. sensor scale	
Hi.S	1,60	3,00	10,00	16,00	25,00	40,00	max sensor scale	
oFS	0	0	0	0	0	0	offset of input correction	
Lo.L	0,00	0,00	0,00	0,00	0,00	0,00	lower set-point setting	
Hi.L	1,60	3,00	10,00	16,00	25,00	40,00	upper set-point setting	

Out	
A1.r	0
A1.t	3 (mode AL1 =inverse-relative-normal)
rL.1	2 (AL1)
rL.2	18 (open)
rL.3	19 (close)
rEL	0
A.ty	9 (type of servocontrol command)
Ac.t	12 (servocontrol running time: SQN72.4/STA12=12; SQM40.265=30)
t_Lo	2
t_Hi	0.0
t.on	2
t.oF	0.0
dE.b	0,1 (dead zone in % of end scale)

PAS	99 then push and keep pushed F until visualization of Hrd	
Hrd		
CtrL	6 (PID warm)	
AL.nr	1	
but	1	
diSP	0	
Ld.1	1	
Ld.2	28	
Ld.3	20	

Keep pushed F until you visualize **PASS**, release F and through the arrows set **99**, push F and visualize **Pro** (protection code) from **128**, through the arrows, bring it back to **12**, and keep F pushed until you come back to set-point value.

### Manual operation:

Keep pushed the lower left key for at least 5 sec.

The instrument will enter the "MAN" mode (see also "Ld1" switching on).

Through the arrows, "Open" and "Close" outputs are activated.

To come back to normal working keep the lower left key pushed for at least 5 sec.

### Software switch off :

By keeping pushed keys **Arrow up** + **F** for more than 5 sec. the instrument switches off the software, does not command the outputs and visualize only the variable of process measured by the probe. To restore keep pushed **F** for more than 5 sec.

### Verify wiring of the sensor



# Regulation of the set-point = **80**

It can be modified by using arrows "up" and "down".

by pushing <b>r</b> you go to parameters.	
Hy.P	10 (hysteresis positive for output 1 terminals 21-22 (ex Q13-Q14)
Hy.n	-5 (hysteresis negative for output 1 terminals 21-22 (ex Q13-Q14)

Keep pushing F until you see **PASS**, release F and through the arrows set **99**, push F and visualize **Pro** (protection code) default is **12**, through the arrows set **128** and push F, keep it pushed until all parameters **InF**, **CFG**, **InP**, **Out**, **PASS** are visualized.

CFG	
S.tun	0
hPb	1,2
hlt	5,83
hdt	1,33

InP	
tyP	2 (thermocouple <b>K</b> 0÷1300°C) / 0 (thermocouple <b>J</b> 0÷1000°C)
dP_S	0 (no decimal) / 1 (1 decimal)
Lo.S	0 (min. sensor scale)
Hi.S	1300 (max sensor scale for tc K) / 1000 (max sensor scale for tc J)
oFS	0 (offset of input correction)
Lo.L	0 (lower set-point range limit)
Hi.L	1300 (upper set-point range limit) per tc $K$ / 1000 for tc $J$

Out		
A1.r	0	
A1.t	3 (mode AL1 =inverse-relative-normal)	
rL.1	2 (AL1)	
rL.2	18 (open)	
rL.3	19 (close)	
rEL	0	
A.ty	9 (type of servocontrol command)	
Ac.t	12 (servocontrol running time: SQN72.4/STA12=12; SQM40.265=30)	
t_Lo	2	
t_Hi	0.0	
t.on	2	
t.oF	0.0	
dE.b	0,1 (dead zone in % of end scale)	

PAS	99 then push and keep pushed <b>F</b> until visualization of <b>Hrd</b>	
Hrd		
CtrL	6 (PID warm)	
AL.nr	1	
but	1	
diSP	0	
Ld.1	1	
Ld.2	28	
Ld.3	20	

Keep pushed F until you visualize **PASS**, release F and through the arrows set **99**, push F and visualize **Pro** (protection code) from **128**, through the arrows, bring it back to **12**, and keep F pushed until you come back to set-point value.

### Manual operation:

Keep pushed the lower left key for at least 5 sec. The instrument will enter the "MAN" mode (see also "Ld1" switching on). Through the arrows, "Open" and "Close" outputs are activated. To come back to normal working keep the lower left key pushed for at least 5 sec.

### Software switch off :

By keeping pushed keys **Arrow up** + **F** for more than 5 sec. the instrument switches off the software, does not command the outputs and visualize only the variable of process measured by the probe. To restore keep pushed **F** for more than 5 sec.

# RWF50.2x & RWF50.3x



User manual

M12922CB Rel.1.0 07/2012

**DEVICE INSTALLATION** Install the device using the relevant tools as shown in the figure. To wire the device and sensors, follow the instructions on the burner wiring diagram.





### FRONT PANEL



NAVIGATION MENU



RWF5 is preset good for 90% of applications. However, you can set or edit parameters as follow:

### Set-point: set or modification:

When the burner is in stand-by, (safety loop open, that is terminals 3-4/T1-T2 on the 7 pole plug open) push the **Enter** button: on the lower display (green) **Opr** appears; push **Enter** again and in the same display **SP1** appears. Push **Enter** again and the lower display (green **SP1**) flashes. Using the **up and down arrows** change the set-point on the upper display (red).Push **Enter** to confirm and push **ESC** more times to get the home position.

### PID parameters set and modifications (see table below):

- Push Enter button, on the green display **Opr** appears; using the **down arrow**, scroll until group **PArA** is reached and push Enter.
- on the green display Pb1 e appears and on the red one the set parameter.
- Push is sequence the down or up arrow the menu is scrolled.
- Push Enter to select and the arrows to choose the desired value. Enter to confirm.

Parameter	Display	Range	Factory setting	Remarks
Proportional band	PB.1	1 9999 digit	10	Typical value for temperature
Derivative action	dt	0 9999 sec.	80	Typical value for temperature
Integral action	rt	0 9999 sec.	350	Typical value for temperature
Dead band (*)	db	0 999,9 digit	1	Typical value
Servocontrol running time	tt	10 3000 sec.	15	Set servocontrol running time
Switch-on differential (*)	HYS1	0,01999 digit	-5	Value under setpoint below which the burner switches back on (1N-1P closes)
Switch-off differential 2° stage (*)	HYS2	0,0 HYS3	3	(enable only with parameter <b>bin1</b> = 4)
Upper switch-off differential (*)	HYS3	0,0… 9999 digit	5	Value over setpoint above which the burner switches off (1N-1P opens)
Switch-on differential on cooling controller (*)	HYS4	0,0… 9999 digit	5	Do not used (enable only with parameter <b>CACt</b> = 0)
Switch-off differential 2° stage on cooling controller (*)	HYS5	HYS6…0,0 digit	5	Do not used (enable only with parameters <b>CACt</b> = 0 and <b>bin1</b> = 4)
Upper switch-off differential on cooling controller (*)	HYS6	0,01999 digit	5	Do not used (enable only with parameter <b>CACt</b> = 0)
Delay modulation	q	0,0 999,9 digit	0	Do not alter

(\*)Parameters affected by setting of decimal place (**ConF > dISP** parameter **dECP**)

### Setting the kind of sensor to be connected to the device:

- push the Enter button: on the lower display (green) **Opr** appears. Using the **up and down arrows** find **ConF.** Push Enter to confirm.
- Now on the green display the group InP appears. Push Enter and InP1 is displaied. Enter to confirm.
- You are inside InP1; the green display shows Sen1 (sensor type), while the red display shows the chosen sensor code
- Push Enter to enter the Sen1 parameter, then choose the desired sensor using the arrows. Push Enter to confirm and ESC to escape.
- Once selected the sensor, you can modify all the other parameters using **up and down arrows** according to the tables here below.

Parameter	Value	Description
SEn1	1	Pt100 3 fili
type of sensor for	2	Pt100 2 fili
analog input 1	3	Pt1000 3 fili
	4	Pt1000 2 fili
	5	Ni1000 3 fili
	6	Ni1000 2 fili
	7	0 ÷ 135 ohm
	15	0 ÷ 20mA
	16	4 ÷ 20mA
	17	0 ÷ 10V
	18	0 ÷ 5V
	19	1 ÷ 5V
OFF1		Using the measured value correction (offset), a measured
sensor offset	-1999 <b>0</b> +9999	value can be corrected to a certain degree, either up or down
SCL1		In the case of a measuring transducer with standard signal, the
scale low level		physical signal is assigned a display value here
	-1999 <b>0</b> +9999	(for input ohm, mA, V)
SCH1		In the case of a measuring transducer with standard signal, the
scale high level		physical signal is assigned a display value here
	-1999 <b>100</b> +9999	(for input ohm, mA, V)
dF1		Is used to adapt the digital 2nd order input filter
digital filter	0 <b>0,6</b> 100	(time in s; $0 \text{ s} = \text{filter off}$ )
Unit	1	1 = degrees Celsius
temperature unit	2	2 = degrees Fahrenheit

### ConF > InP >InP1

(**bold** = factory settings)

### Remark:

RWF50.2 e RWF50.3 cannot be connected to thermocouples.

If thermocouples have to be connected, convert the signal to a 4-20 mA one and set the RWF accordingly.

# ConF > Cntr

Parameter	Value	Description
CtYP	1	1 = 3-position controller (open-stop-close only RWF50.2)
controller type	2	2 = continuative action controller (only RWF50.3)
CACt	1	1 = heating controller
control action	0	0 = cooling controller
SPL		
least value of the		set-point limitation prevents entry of values outside the defined
set-point range	-1999 <b>0</b> +9999	range
SPH		
maximum value of the		set-point limitation prevents entry of values outside the defined
set-point range	-1999 <b>100</b> +9999	range
oLLo		
set-point limitation		
start, operation limit		
low	<b>-1999</b> +9999	lower working range limit
oLHi		
set-point limitation		
end, operation limit		
high	-1999 <b>+9999</b>	upper working range limit

(**bold** = factory settings)

# ConF > rAFC

Activation boiler shocl	c termic protetion:	
RWF50 can activate th	e thermal shock protection on	ly on sites where the set-point is lower than 250°C and according
to <b>rAL</b> parameter.		
Parameter	Value	Description
FnCT		Choose type of range degrees/time
function	0	0 = deactivated
	1	1 = Kelvin degrees/minute
	2	2 = Kelvin degrees/hour
rASL		Slope of thermal shock protection (only with functions 1 and 2)
ramp rate	<b>0,0</b> 999,9	
toLP tolerance band ramp	<b>0</b> 9999	width of tolerance band (in K) about the set-point <b>0 = tolerance band inactive</b> 40 40 TREASTOR
rAL ramp limit	<b>0</b> 250	Ramp limit. When this value is lower than the temperature set- point, the RWF controls the output increasing the temp set point step by step according to rASL. If this is over the temp set point, the control is performed in cooling.

(**bold** = factory settings)

# ConF > OutP (parameter under group only for RWF50.3)

Parameter	Value	Description
FnCt		1 = analog input 1 doubling with possibility to convert
tipo di controllo	1	(depending on par SiGn)
	4	4 = modulation controller
SiGn		physical output signal (terminals A+, A-)
type of output signal	0	0 = 0÷20mA
	1	1 = 4÷20mA
	2	2 = 0÷10V
rOut		
Value when out of		
input range	<b>0</b> 101	signal (in percent) when measurement range is crossed
oPnt		value range of the output variable is assigned to a physical
zero point		output signal Per default, the setting corresponds to 0100%
		angular positioning for the controller outputs (terminals A+, A-)
	-1999 <b>0</b> +9999	(effective only with <b>FnCt</b> = 1)
End		value range of the output variable is assigned to a physical
End value		output signal Per default, the setting corresponds to 0100%
		angular positioning for the controller outputs (terminals A+, A-)
	-1999 <b>100</b> +9999	(effective only with <b>FnCt</b> = 1)

(**bold** = factory settings)

# ConF > binF

Parameter	Value	Description
bin1		0 = without function
digital inputs		1 = set-point changeover (SP1 / SP2)
(terminals DG - D1)		2 = set-point shift ( <b>Opr</b> > <b>dSP</b> parameter = value of set-point
	0	modify)
	1	4 = changeover of operating mode
	2	open – modulating operation;
	4	close – 2 stage operation.

(**bold** = factory settings)

# ConF > dISP

Parameter	Value	Description
diSU		display value for upper display:
upper display	0	0 = display power-off
(red)	1	1 = analog input value
	4	4 = Controller's angular positioning
	6	6 = set-point value
	7	7 = end value with thermal shock protection
diSL		display value for lower display:
lower display	0	0 = display power-off
(green)	1	1 = analog input value
	4	4 = Controller's angular positioning
	6	6 = set-point value
	7	7 = end value with thermal shock protection
tout		time (s) on completion of which the controller returns
timeout	0 <b>180</b> 250	automatically to the basic display, if no button is pressed
dECP	0	0 = no decimal place
decimal point	1	1 = one decimal place
	2	2 = two decimal places
CodE	0	0 = no lockout
level lockout	1	1 = configuration level lockout (ConF)
	2	2 = Parameter and configuration level lockout (PArA & ConF)
	3	3 = keyboard lockout

(**bold** = factory settings)

### Manual control :

- in order to manual change the burner load, while firing keep pushing the **ESC** button for more than 5 s; on the lower green display **Hand** appears.
- using the UP and DOWN arrows, the load varies.
- Keep pushing the ESC button for getting the normal operation again.
- NB: every ime the device shuts the burner down (start led switched off contact 1N-1P open), the manual control is not active.

### Device self-setting (auto-tuning):

If the burner in the steady state does not respond properly to heat generator requests, you can activate the Device's self-setting function, which recalculates PID values for its operation, deciding which are most suitable for the specific kind of request



### Display of software version :



The software version is shown by pushing **Enter + UP arrow** on the upper display

### **Electric connection :**



### Matches terminals between RWF50.2 and RWF40.0x0

ка o Ø	K2 Ø	КЗ	1N Ø	SIE 1P Ø	MENS L1 Ø	RWF ₽	50.2		G- Ø	G+	13 Ø	12 Ø	11 Ø
o Q	Y1	Y2	Q 13	SIEM Q14	IENS   L1 Ø	RWF4 Ø	0.0x0 Te	U1	G- Ø	G+	M1	l1 ∅	G1+

Parameters summarising for RWF50.2x:

	Conf						Conf								
Navigation menù			Inp						DATA						0
Types of probe	SEn1	OFF1	SCL1	SCH1	Unit	SPL	ntr SPH	dISP	Pb. 1	Pb. 1 dt rt tt HYS1 (*)		ArA HYS1 (*)	HYS3 (*)	Opr SP1 (*)	
Siemens QAE2120	6	0	needless	needless	1	30	95	1	10	80	350	(#)	-5	5	80 °C
Siemens QAM2120	6	0	needless	needless	1	0	80	1	10	80	350	(#)	-2,5	2,5	40°C
Pt1000 (130°C max.)	4	0	needless	needless	1	30	95	1	10	80	350	(#)	-5	5	80°C
Pt1000 (350°C max.)	4	0	needless	needless	1	0	350	1	10	80	350	(#)	-5	10	80°C
Pt100 (130°C max.)	1	0	needless	needless	1	0	95	1	10	80	350	(#)	-5	5	80°C
Pt100 (350°C max)	1	0	needless	needless	1	0	350	1	10	80	350	(#)	-5	10	80°C
Probe 4÷20mA / 0÷1,6bar	16	0	0	160	needless	0	160	0	5	20	80	(#)	0	20	100 kPa
Probe 4+20mA / 0+3bar	16	0	0	300	needless	0	300	0	5	20	80	(#)	0	20	200 kPa
Probe 4÷20mA / 0÷10bar	16	0	0	1000	needless	0	1000	0	5	20	80	(#)	0	50	600 kPa
Probe 4÷20mA / 0÷16bar	16	0	0	1600	needless	0	1600	0	5	20	80	(#)	0	80	600 kPa
Probe 4÷20mA / 0÷25bar	16	0	0	2500	needless	0	2500	0	5	20	80	(#)	0	125	600 kPa
Probe 4÷20mA / 0÷40bar	16	0	0	4000	needless	0	4000	0	5	20	80	(#)	0	200	600 kPa
Siemens QBE2002 P4	17	0	0	400	needless	0	400	0	5	20	80	(#)	0	20	200 kPa
Siemens QBE2002 P10	17	0	0	1000	needless	0	1000	0	5	20	80	(#)	0	50	600 kPa
Siemens QBE2002 P16	17	0	0	1600	needless	0	1600	0	5	20	80	(#)	0	80	600 kPa
Siemens QBE2002 P25	17	0	0	2500	needless	0	2500	0	5	20	80	(#)	0	125	600 kPa
Siemens QBE2002 P40	17	0	0	4000	needless	0	4000	0	5	20	80	(#)	0	200	600 kPa
Segnale 0÷10V	17	0	to be fixed	to be fixed	needless	to be fixed	to be fixed	to be fixed	5	20	80	(#)	to be fixed	to be fixed	to be fixed
Segnale 4÷20mA	16	0	to be fixed	to be fixed	needless	to be fixed	to be fixed	to be fixed	5	20	80	(#)	to be fixed	to be fixed	to be fixed

NOTE :

(#) tt – servo control run time

(#) the serve control run time SQL33 ; STM30; SQM10; SQM40; SQM50; SQM54 = **30** (secondi) - STA12B3.41; SQN30.251; SQN72.4A4A20 = **12** (secondi) (\*) These values are factory set - values <u>must be</u> set during operation at the plant based on the real working temperature/pressure value. WARNING : With pressure probes the parameters SP1, SCH, SCL, HYS1, HYS3 must be selected, and visualized in kPa (kilo Pascal). (<u>1bar = 100.000Pa = 100kPa</u>)

### **APPENDIX: PROBES CONNECTION**

To assure the utmost comfort, the control system needs reliable information, which can be obtained provided the sensors have been installed correctly. Sensors measure and transmit all variations encountered at their location.

Measurement is taken based on design features (time constant) and according to specific operating conditions. With wiring run in raceways, the sheath (or pipe) containing the wires must be plugged at the sensor's terminal board so that currents of air cannot affect the sensor's measurements.

### Ambient probes (or ambient thermostats)

### Installation

The sensors (or room thermostats) must be located in

reference rooms in a position where they can take real temperature measurements without being affected by foreign factors.

ioreign lactors.



### It's good to be admired ...even better to be effective

Heating systems: the room sensor must not be installed in rooms with heating units complete with thermostatic valves. Avoid all sources of heat foreign to the system.





Outside probes (weather) Installation

In heating or air-conditioning systems featuring adjustment in response to outside temperature, the sensor's positioning is of paramount importance.



**General rule:** on the outer wall of the building where the living rooms are, never on the south-facing wall or in a position where they will be affected by morning sun. If in any doubt, place them on the north or north-east façade.

### Positions to be avoided



Avoid installing near windows, vents, outside the boiler room, on chimney breasts or where they are protected by balconies, cantilever roofs.

The sensor must not be painted (measurement error).

### Location

On an inner wall on the other side of the room to heating unitsheight above floor 1.5 m, at least 1.5 m away from external sources of heat (or cold).



### Installation position to be avoided

near shelving or alcoves and recesses, near doors or win-dows, inside outer walls exposed to solar radiation or currents of cold air, on inner walls with heating system pipes, domestic hot water pipes, or cooling system pipes running through them.

### Duct or pipe sensors

### Installing temperature sensors

For measuring outlet air:

- after delivery fan or
- after coil to be controlled, at a distance of at least 0,5 m

For measuring room temperature:

• before return air intake fan and near room's return airintake. For measuring saturation temperature: after mist eliminator.



Bend 0.4m sensor by hand (never use tools) as illustrated.



Use whole cross-section of duct, min. distance from walls 50 mm, radius of curvature 10 mm for 2m or 6m sensors.

### Installing combined humidity sensors

As max. humidity limit sensor on outlet (steam humidifiers).



### Installing pressure sensors

- A installation on ducts carrying fluids at max. temperature 80°C
- B installation on ducts at temperature over 80°C and for refrigerants
- C installation on ducts at high temperatures:
  - increase length of siphon
  - place sensor at side to prevent it being hit by hot air coming from the pipe.



### Installing differential pressure sensors for water

- Installation with casing facing down not allowed.-With temperature over 80°C, siphons are needed.
- To avoid damaging the sensor, you must comply with the following instructions

### when installing:

- make sure pressure difference is not greater than thevalue permitted by the sensor
- when there are high static pressures, make sure you insert shutoff valves A-B-C.

### Putting into operation

Start disable 1=open C1=open C 2=open A2=close B 3=open B3=close A 4= close C



### Immersion or strap-on sensors



Placing the probes (QAD22.../QAE21.../QAP21.../RCA...)

With pumps on outlet

### with 3 ways valves / with 4 ways valves



With pumps on return

with 3 ways valves / with 4 ways valves





### Immersion probes installation

Sensors must be installed on the stretch of pipe in which fluid circulates all the time.

The rigid stem (sensing element doing the measuring) must be inserted by at least 75mm and must face the direction of flow.

Recommended locations: on a bend or on a straight stretch of pipe but tilted by  $45^\circ$  and against the flow of fluid.

Protect them to prevent water from infiltrating (dripping gates, condensation from pipes etc.)

### Installing QAD2.. strap-on sensors

Make sure fluid is circulating in the chosen location.

Eliminate insulation and paintwork (including rust inhibitor) on a min. 100mm length of pipe.

Sensors come with straps for pipes up to 100 mm in diameter

### Strap-on or immersion sensors? QAD2.. strap-on sensors

Advantages :

- 10 sec. time constant
- Installed with system running (no plumbing work)
- Installation can be changed easily if it proves incorrect.

### Limits:

- Suitable for pipe diameters max. 100 mm
- Can be affected by currents of air etc.

### QAE2... immersion sensors

Advantages:

- Measure "mean" fluid temperature
- No external influence on measurement such as: currents of air, nearby pipes etc.

### Limits:

- Time constant with sheath: 20 sec.
- Hard to change installation position if it proves incorrect.

Installing differential pressure probes for air



A - Control a filter (clogging)



B - Control a fan (upstream/downstream)



C - Measurement of difference in pressure between two ducts



D - Measurement of difference in pressure between two rooms or of inside of duct and outside

### **Basic principles**

Measuring static pressure(i.e. pressure exerted by air on pipe walls)



### Measuring dinamic pressure



Key

- y Kg/m<sup>3</sup>, specific weight of air m/s, air speed
- g 9.81 m/s<sup>2</sup> gravity acceleration
- Pd mm C.A., dynamic pressure

### Measuring total pressure



# Spare parts

Description	Code
Modulator RWF50.2 (uscita a 3 punti - apri, fermo, chiudi)	2570148
Modulator RWF50.3 (uscita continua 0÷20mA, 4÷20mA, 0÷10V)	2570149
Temperature probe Siemens QAE2120.010A (30÷130°C)	2560101
Temperature probe Siemens QAM2120.040 (-15÷+50°C)	2560135
Thermoresistor Pt1000 ø6mm L100mm (30÷130°C)	2560188
Thermoresistor Pt1000 ø10mm L200mm (0÷350°C)	2560103
Thermoresistor Pt100 ø10mm L200mm (0÷350°C)	2560145
Thermoresistor Pt100 ø8mm L85mm (0÷120°C)	25601C3
Pressure probe Siemens QBE2 P4 (0÷4bar)	2560159
Pressure probe Siemens QBE2 P10 (0÷10bar / signal 0÷10V)	2560160
Pressure probe Siemens QBE2 P16 (0÷16bar / signal 0÷10V)	2560167
Pressure probe Siemens QBE2 P25 (0÷25bar / signal 0÷10V)	2560161
Pressure probe Siemens QBE2 P40 (0÷40bar / signal 0÷10V)	2560162
Pressure probe Danfoss MBS 3200 P 1,6 (0÷1,6bar / signal 4÷20mA)	2560189
Pressure probe Danfoss MBS 3200 P 10 (0÷10bar / signal 4÷20mA)	2560190
Pressure probe Danfoss MBS 3200 P 16 (0÷16bar / signal 4÷20mA)	2560191
Pressure probe Danfoss MBS 3200 P 25 (0÷25bar / signal 4÷20mA)	2560192
Pressure probe Danfoss MBS 3200 P 40 (0÷40bar / signal 4÷20mA)	2560193
Pressure probe Siemens 7MF1565-3BB00-1AA1 (0÷1,6bar / signal 4÷20mA)	25601A3
Pressure probe Siemens 7MF1565-3CA00-1AA1 (0÷10bar / signal 4÷20mA)	25601A4
Sonda di pressione Siemens 7MF1565-3CB00-1AA1 (0÷16bar / signal	25601A5
Pressure probe Siemens 7MF1565-3CD00-1AA1 (0÷25bar / signal 4÷20mA)	25601A6
Pressure probe Siemens 7MF1565-3CE00-1AA1 (0÷40bar / signal 4÷20mA)	25601A7
Pressure probe Gefran E3E B1V6 MV (0÷1,6bar / segnale 4÷20mA)	25601C4
Pressure probe Danfoss E3E B01D MV (0÷10bar / segnale 4÷20mA)	25601C5
Pressure probe Danfoss E3E B16U MV (0÷16bar / segnale 4÷20mA)	25601C6
Pressure probe Danfoss E3E B25U MV (0÷25bar / segnale 4÷20mA)	25601C7
Pressure probe Danfoss E3E B04D MV (0÷40bar / segnale 4÷20mA))	25601C8

Note: Specifications and data subject to change. Errors and omissions excepted.

# **KM3 Modulator**

**USER MANUAL** 

M12927CA Rel.1.0 10/2020

# MOUNTING



# **DISPLAY AND KEYS**



	Operator Mode	Editing Mode
Ţ	Access to: - Operator Commands (Timer, Setpoint selection) - Parameters - Configuration	Confirm and go to Next parameter
	Access to: - Operator additional information (Output value, running time)	Increase the displayed value or select the next element of the parameters list
	Access to: - Set Point	Decrease the displayed value or select the previous element
ß	Programmable key: Start the programmed function (Autotune, Auto/Man, Timer)	Exit from Operator commands/Parameter setting/Configuration

# **CONNECTIONS DIAGRAM**



### Probe connection:

- PT1000/NTC/PTC: between terminal 3 and 2
- PT 100: between terminal 3 and 2 with terminal 1
- **Passive pressure probe** 0/4-20 mA: between terminal 4 (+) e 1 (-) Note: out4 must be activated (IO4F must be setted to ON)
- **Powered pressure probe** 0/4-20 mA between terminal 4 (power supply), 2 (negative) e 1 (positive) Note: set IO4F to ON to activate Out4

### Power supply connection:

- Neutral wire: terminal 9
- Phase: terminal 10 (100...240 Vac)
- Close terminals 15-16 to switch to the set point 2

### Output connection:

- Channel 1: terminal 7 and 8 (burner on off)
- Channel 2: terminal 11 and 12 (servomotor opens)
- Channel 3: terminal 13 and 14 (servomotor closes)

# SETPOINT AND HYSTERESIS CONFIGURATION (SP, AL1, HAL1 parameters)

Push the 🛃 button to enter into the setpoint configuration:



To return to normal mode, press the 😨 key for 3 seconds or wait the 10s timeout

### **Operation example**



# LIMITED ACCESS LEVEL

Proceed as follows to change some parameters that are not visible in standard user mode:



Param	Description	Values	Default
SEnS	Input type	Pt1 = RTD Pt100 Pt10 = RTD Pt1000 0.20 = 020mA 4.20 = 420mA Pressure probe 0.10 = 010V 2.10 = 210V crAL= Thermocouple K	Depends on the probe
SP	Set point 1	SPLL SPLH	
AL1	AL1 threshold	AL1L AL1H (E.U.)	
HAL1	AL1 hysteresis	1 9999 (E.U.)	
Pb	Proportional band	1 9999 (E.U.)	
ti	Integral time	0 (oFF) 9999 (s)	
td	Derivative time	0 (oFF) 9999 (s)	See page 7
Str.t	Servomotor stroke time	51000 seconds	
db.S	Servomotor dead band	0100%	
SPLL	Minimum set point value	-1999 SPHL	
SPHL	Maximum set point value	SPLL 9999	
dp	Decimal point position	0 3	
SP 2	Set point 2	SPLLSPLH	60
A.SP	Selection of the active set point	"SP" " nSP"	SP

To exit the parameter setting procedure press the 😨 key (for 3 s) or wait until the timeout expiration (about 30 seconds)

Parameter Group	inP						AL1		Ъ Б Ц					SP		
Parameter	Sens	dþ	SSC	FSc	unit	104.F	AL1	HAL1	Pb	ti	td	Str.t	db.S	SPLL	SPHL	SP
						(**)	(***)	(***)	(***)	(***)	(***)					(***)
Probes		Dec	Scale	Scale			Off	No	٩		σ	servo	Band	SP	SP	Set
		Point	Min	Max								time s	Mo.	Min	Max	point
Pt1000 (130°C max)	Pt10	1			°	on	5	10	10	350	-	*	5	30	95	80
Pt1000 ( 350°C max)	PT10	1			°C	on	10	10	10	350	1	*	5	0	350	80
Pt100 (130°C max)	PT1	1			ç	on	5	10	10	350	-	*	5	0	95	80
Pt100 (350°C max)	Pt1	1			°	on	10	10	10	350	-	*	5	0	350	80
Pt100 (0+100°C 4+20mA)	4.20	1	0	100		on	5	10	10	350	1	*	5	0	95	80
Thermocouple K (1200°C max)	crAL	0			°	on	20	25	10	350	-	*	5	0	1200	80
Thermocouple J (1000°C max)	ſ	0			°C	on	20	25	10	350	1	*	5	0	1000	80
4-20mA / 0-1,6barPressure probe	4.20	0	0	160		on	20	20	5	120	-	*	5	0	160	100
4-20mA / 0-10bar Pressure probe	4.20	0	0	1000		on	50	50	5	120	-	*	5	0	1000	600
4-20mA / 0-16bar Pressure probe	4.20	0	0	1600		on	80	80	5	120	-	*	5	0	1600	600
4-20mA / 0-25bar Pressure probe	4.20	0	0	2500		on	125	125	5	120	-	*	5	0	2500	600
4-20mA / 0-40bar Pressure probe	4.20	0	0	4000		on	200	200	5	120	1	*	5	0	4000	600
QBE2002 / 0-25bar Pressure probe	0.10	0	0	2500		On	125	125	5	120	-	*	5	0	2500	600

7

Probe parameters configuration MODULATORE ASCON KM3

Note:

(\*) Str.t - Servomotor stroke time SQL33; STM30; SQM10; SQM40; SQM50; SQM54 = 30 (Seconds) STA12B3.41; SQN30.251; SQN72.4A4A20 = 12 (Seconds)

# (\*\*) Out 4 ... on Display led °4 must be switched on, otherwise change the io4.F parameter value from "on" to "out4", confirm the value, quit the configuration mode then change again the io4.F parameter value from "out4" to "on".

(\*\*\*) Factory settings. These values must be adapted to machine conditions

N.B. For pressure probe, SP, SPHL, SPLL parameters values are expressed in Kpa (1 bar = 100 Kpa).

# CONFIGURATION

### How to access configuration level

The configuration parameters are collected in various groups. Every group defines all parameters related with a specific function (e.g.: control, alarms, output functions).

- 1. Push the 🛃 button for more than 5 seconds. The upper display will show PASS while the lower display will show 0.
- Using  $\triangle$  and  $\nabla$  buttons set the programmed password. 2.

According to the entered password, it is possible to see a part of the parameters listed in the "configuration parameters" section.

- a. Enter "30" as password to view all the configuration parameters
- b. Enter "20" as password to view the parameters of the "limited access level". At this point, only the parameters with attribute Liv = A or Liv = O will be editable. Leave the password blank to edit "user level" parameters, that are identified by attribute Liv = O
- C.
- 3. Push the 🛃 button. If the password is correct the display will show the acronym of the first parameter group preceded by the symbol: <sup>¬</sup>. In other words the upper display will show: <sup>¬</sup> inP (group of the **Input parameters**).

The instrument is in configuration mode. To press 😨 for more than 5 seconds, the instrument will return to the "standard display.

### Keyboard functions during parameter changing:

	Operator Mode
l	When the upper display is showing a group and the lower display is blank, this key allows to enter in the selected group. When the upper display is showing a parameter and the lower display is showing its value, this key allows to store the selected value for the current parameter and access the next parameter within the same group.
	Allows to increase the value of the selected parameter.
	Allows to decrease the value of the selected parameter.
Ъ	Short presses allow you to exit the current group of parameters and select a new group. A long press terminates the configuration procedure (the instrument returns to the normal display).
ပ L	These two keys allow to return to the previous group. Proceed as follows:
	Push the 🔛 button and maintaining the pressure, then push the 🛁; release both the buttons.

### **Configuration Parameters**

inP	GRO	JP - inpu	t confiuration		
Liv	N°	Param	Description	Values	Default
A	1	SEnS	Input type	Pt1 = RTD Pt100 Pt10 = RTD Pt1000 0.20 = 020mA 4.20 = 420mA Pressure probe 0.10 = 010V 2.10 = 210V crAL= Thermocouple K	Depends on the probe
A	2	dp	Decimal point position	0 3	See page 7
A	3	SSc	Initial scale read-out for linear inputs (avaiable only if SEnS parameter is not equal to Pt1, Pt10, crAL values)	-1999 9999	0
С	4	FSc	Full scale read-out for linear input inputs (avaiable only if SEnS parameter is not equal to Pt1, Pt10, crAL values)	-1999 9999	Depends on the probe
С	5	unit	Unit of measure (present only in the case of temperature probe)	°C/°F	°C
С	6	Fil	Digital filter on the measured value	0 (= OFF) 20.0 s	1.0
С	7	inE	Selection of the Sensor Out of Range type that will enable the safety output value	or = Over range ou = Under range our = over e under range	or

С	8	oPE	Safety output value	-100 100	0
С	9	io4.F	I/O4 function selection	on = Out4 will be ever ON (used as a transmitter power supply) ,out4 = Uscita 4 (Used as digital output 4), dG2c = Digital input 2 for contact closure, dG2U = Digital input 2 driven by 12 24 VDC	on
С	10	diF1	Digital input 1 function	oFF = Not used, 1 = Alarm reset, 2 = Alarm acknowledge (ACK), 3 = Hold of the measured value, 4 = Stand by mode, 5 = Manual mode, 6 = HEAt with SP1 and CooL with SP2, 7 = Timer RUN/Hold/Reset, 8 = Timer Run, 9 = Timer Reset, 10 = Timer Run/Hold, 11 = Timer Run/Reset, with lock, 13 = Program Start, 14 = Program Reset, 15 = Program Run/Hold, 16 = Program Run/Hold, 17 = Program Run/Reset, 18 = Sequential SP selection, 19 = SP1 - SP2 selection, 20 = SP1 SP4 binary selection, 21 = Digital inputs in parallel	19
С	12	di.A	Digital Inputs Action (DI2 only if configured)	0 = DI1 direct action, DI2 direct action 1 = DI1 reverse action, DI2 direct action 2 = DI1 direct action, DI2 reverse action 3 = DI1 reverse action, DI2 reverse action	0

Out	GRO	UP- Outp	out parameters		
Liv	N°	Param	Description	Values	Default
С	14	o1F	Out 1 function	AL = Alarm output	AL
С	15	o1AL	Initial scale value of the analog retransmission	-1999 Ao1H	1
С	18	o1Ac	Out 1 action	dir = Direct action rEU = Reverse action dir.r = Direct with reversed LED ReU.r = Reverse with reversed LED	rEUr.r
С	19	o2F	Out 2 function	H.rEG = Heating output	H.rEG
С	21	o2Ac	Out 2 action	dir = Direct action rEU = Reverse action dir.r = Direct with reversed LED ReU.r = Reverse with reversed LED	dir
С	22	o3F	Out 3 function	H.rEG = Heating output	H.rEG
С	24	o3Ac	Out 3 action	dir = Direct action rEU = Reverse action dir.r = Direct with reversed LED ReU.r = Reverse with reversed LED	dir

AL1	AL1 GROUP - Alarm 1 parameters					
Liv	N°	Param	Descrizione	Values	Default	
С	28	AL1t	Tipo allarme AL1	nonE = Alarm not used LoAb = Absolute low alarm HiAb = Absolute high alarm LHAo = Windows alarm in alarm outside the windows LHAI = Windows alarm in alarm inside the	HidE	

				windows	
				SE.br = Sensor Break	
				LodE = Deviation low alarm (relative)	
				HidE = Deviation high alarm (relative)	
				LHdo = Relative band alarm in alarm out of the	
				band	
				LHdi = Relative band alarm in alarm inside the	
				band	
С	29	Ab1	Alarm 1 function	0 15	0
				+1 = Not active at power up	
				+2 = Latched alarm (manual reset)	
				+4 = Acknowledgeable alarm	
				+8 = Relative alarm not active at set point change	
С	30	AL1L	For High and low alarms, it is the low limit	-1999 AL1H (E.U.)	-199.9
			of the AL1 threshold;		
			For band alarm, it is low alarm threshold		
С	31	AL1H	For High and low alarms, it is the high	AL1L 9999 (E.U.)	999.9
			limit of the AL1 threshold;		
			For band alarm, it is high alarm threshold		
0	32	AL1	AL1 threshold	AL1L AL1H (E.U.)	See
					page 7
0	33	HAL1	AL1 hysteresis	1 9999 (E.U.)	See
					page 7
С	34	AL1d	AL1 delay	0 (oFF) 9999 (s)	oFF
С	35	AL10	Alarm 1 enabling during Stand-by mode and	0 = Alarm 1 disabled during Stand by and out of	1
			out of range conditions	range	
				1 = Alarm 1 enabled in stand by mode	
				2 = Alarm 1 enabled in out of range condition	
				3 = Alarm 1 enabled in stand by mode and in	
				overrange	
				condition	

GRUPPO AL2 - parametri allarme 2						
Liv	N°	Param	Description	Values	Default	
С	36	AL2t	Alarm 2 type	nonE = Alarm not used LoAb = Absolute low alarm HiAb = Absolute high alarm LHAo = Windows alarm in alarm outside the windows LHAI = Windows alarm in alarm inside the windows SE.br = Sensor Break LodE = Deviation low alarm (relative) HidE = Deviation high alarm (relative) LHdo = Relative band alarm in alarm out of the band LHdi = Relative band alarm in alarm inside the band	SE.br	
С	37	Ab2	Alarm 2 function	0 15 +1 = Not active at power up +2 = Latched alarm (manual reset) +4 = Acknowledgeable alarm +8 = Relative alarm not active at set point change	0	
С	42	AL2d	AL2 hysteresis	0 (oFF) 9999 (s)	oFF	
С	43	AL20	Alarm 2 enabling during Stand-by mode and out of range conditions	<ul> <li>0 = Alarm 2 disabled during Stand by and out of range</li> <li>1 = Alarm 2 enabled in stand by mode</li> <li>2 = Alarm 2 enabled in out of range condition</li> <li>3 = Alarm 2 enabled in stand by mode and in overrange</li> <li>condition</li> </ul>	0	

AL3	AL3 Group - alarm 3 parameters					
Liv	N°	Param	Description	Values	Default	
	44	AL3t	Alarm 3 type	nonE = Alarm not usedLoAb = Absolute low alarmHiAb = Absolute high alarmLHAo = Windows alarm in alarm outside thewindowsLHAI = Windows alarm in alarm inside thewindowsSE.br = Sensor BreakLodE = Deviation low alarm (relative)HidE = Deviation high alarm (relative)LHdo = Relative band alarm in alarm out of thebandLHdi = Relative band alarm in alarm inside the	nonE	

LbA Group - Loop break alarm					
Liv	N°	Param	Descrizione	Values	Default
С	52	LbAt	LBA time	Da 0 (oFF) a 9999 (s)	oFF

rEG	rEG Group - Control parameters					
Liv	N°	Param	Description	Values	Default	
С	56	cont	Control type	Pid = PID (heat and/or) On.FA = ON/OFF asymmetric hysteresis On.FS = ON/OFF symmetric hysteresis nr = Heat/Cool ON/OFF control with neutral zone 3Pt = Servomotor control (available only when Output 2 and Output 3 have been ordered as "M")	3pt	
С	57	Auto	Autotuning selection	<ul> <li>-4 = Oscillating auto-tune with automaticrestart at power up and after all point change</li> <li>-3 = Oscillating auto-tune with manual start</li> <li>-2 = Oscillating -tune with auto-matic start at the first power up only</li> <li>-1 = Oscillating auto-tune with auto-matic restart at every power up</li> <li>0 = Not used</li> <li>1 = Fast auto tuning with automatic restart at every power up</li> <li>2 = Fast auto-tune with automatic start the first power up only</li> <li>3 = FAST auto-tune with automatic restart at power up and after set point change</li> <li>5 = Evo-tune with automatic restart at every power up</li> <li>6 = Evo-tune with automatic start the first power up and after set point change</li> <li>5 = Evo-tune with automatic restart at every power up</li> <li>6 = Evo-tune with automatic start the first power up and after set point change</li> <li>5 = Evo-tune with automatic restart at every power up</li> <li>6 = Evo-tune with automatic start the first power up and after set point change</li> </ul>	7	
С	58	tunE	Manual start of the Autotuning	oFF = Not active on = Active	oFF	
С	59	SELF	Self tuning enabling	no = The instrument does not perform the self- tuning YES = The instrument is performing the self- tuning	No	
---	----	-------	----------------------------------	--------------------------------------------------------------------------------------------------------------------	---------------	
A	62	Pb	Proportional band	1 9999 (E.U.)	See page 7	
A	63	ti	Integral time	0 (oFF) 9999 (s)	See page 7	
A	64	td	Derivative time	0 (oFF) 9999 (s)	See page 7	
С	65	Fuoc	Fuzzy overshoot control	0.00 2.00	1	
С	69	rS	Manual reset (Integral pre-load)	-100.0 +100.0 (%)	0.0	
A	70	Str.t	Servomotor stroke time	51000 seconds	See page 7	
A	71	db.S	Servomotor dead band	0100%	5	
С	72	od	Delay at power up	0.00 (oFF) 99.59 (hh.mm)	oFF	

SP (	P Group - Set point parameters				
Liv	N°	Param	Description	Values	Default
С	76	nSP	Number of used set points	1 4	2
A	77	SPLL	Minimum set point value	-1999 SPHL	See page 7
A	78	SPHL	Maximum set point value	SPLL 9999	See page 7
0	79	SP	Set point 1	SPLL SPLH	See page 7
С	80	SP 2	Set point 2	SPLL SPLH	60
	83	A.SP	Selection of the active set point	"SP" " nSP"	SP
С	84	SP.rt	Remote set point type	RSP = The value coming from serial link is used as remote set point trin = The value will be added to the local set point selected by A.SP and the sum becomes the operative set point PErc = The value will be scaled on the input range and this value will be used as remote SP	trin
С	85	SPLr	Local/remote set point selection	Loc = Local rEn = Remote	Loc
С	86	SP.u	Rate of rise for POSITIVE set point change (ramp UP)	0.01 99.99 (inF) Eng. units per minute	inF
С	87	SP.d	Rate of rise for NEGATIVE set point change (ramp DOWN)	0.01 99.99 (inF) Eng. units per minute	inF

PAn	Grou	p - Oper	ator HMI		
Liv	N°	Param	Description	Values	Default
С	118	PAS2	Level 2 password (limited access level)	oFF (Level 2 not protected by password) 1 200	20
С	119	PAS3	Level 3 password (complete configuration level)	3 300	30
С	120	PAS4	Password livello (livello configurazione a codice)	201 400	300
С	121	uSrb	button function during RUN TIME	nonE = No function tunE = Auto-tune/self-tune enabling. A single press (longer than 1 second) starts the auto-tune oPLo = Manual mode. The first pressure puts the instrument in manual mode (OPLO) while a second one puts the instrument in Auto mode	tunE

				AAc = Alarm reset	
				ASi = Alarm acknowledge	
				chSP = Sequential set point selection	
				St.by = Stand by mode. The first press puts the	
				instrument in stand by	
				mode while a second one puts the instrument in	
				Auto mode.	
				Str.t = Timer run/hold/reset	
				P.run = Program run	
				P.rES = Program reset	
				P.r.H.r = Program run/hold/reset	
С	122	diSP	Display management	Spo = Operative set point	SPo
С	123	di.cL	Display colour	0 = The display colour is used to show the actual	2
				deviation (PV - SP)	
				1 = Display red (fix)	
				2 = Display green (fix)	
				3 = Display orange (fix)	
		diS.t	Display Timeout	oFF (display always ON)	oFF
	125			0.1 99.59 (mm.ss)	
С	126	fiLd	Filter on the displayed value	oFF (filter disabled)	oFF
				From 0.0 (oFF) to 20.0 (E.U.)	
С	128	dSPu	Instrument status at power ON	AS.Pr = Starts in the same way it was prior to the	Auto
				power down	
				Auto = Starts in Auto mode	
				oP.0 = Starts in manual mode with a power	
				output equal to zero	
				St.bY = Starts in stand-by mode	
С	129	oPr.E	Operative modes enabling	ALL = All modes will be selectable by the next	ALL
				parameter	
				Au.oP = Auto and manual (OPLO) mode only will	
				be selectable by the next parameter	
				Au.Sb = Auto and Stand-by modes only will be	
				selectable by the next parameter	
С	130	oPEr	Operative mode selection	If oPr.E = ALL: - Auto = Auto mode	Auto
				- oPLo = Manual mode	
				- St.bY = Stand by mode	
				If oPr.E = Au.oP: - Auto = Auto mode	
				- oPLo = Manual mode	
				If oPr.E = Au.Sb: - Auto = Auto mode	
1				I - St.bY = Stand by mode	

SEr	SEr Group - Serial link parameter				
Liv	N°	Param	Description	Values	Default
С	131	Add	Instrument address	oFF 1 254	1
С	132	bAud	baud rate	1200 = 1200 baud 2400 = 2400 baud 9600 = 9600 baud 19.2 = 19200 baud 38.4 = 38400 baud	9600
С	133	trSP	Selection of the value to be retransmitted (Master)	nonE = Retransmission not used (the instrument is a slave) rSP = The instrument becomes a Master and retransmits the operative set point PErc = The instrument become a Master and it retransmits the power output	nonE

Liv	N°	Param	Description	Values	Default
Liv C	<b>N°</b> 134	Param Co.tY	Description Count type	Values         oFF = Not used         1 = Instantaneous power (kW)         2 = Power consumption (kW/h)         3 = Energy used during program execution. This measure starts from         zero when a program runs end stops at the end of the program. A         new program execution will reset the value         4 = Total worked days: number of hours the instrument is turned ON         divided by 24.         5 = Total worked hours: number of hours the instrument is turned ON.         6 = Total worked days with threshold: number of hours the instrument is turned ON.         6 = Total worked days with threshold: number of hours the instrument is turned ON.         7 = Total worked hours with threshold set in [137] h.Job.         7 = Total worked hours with threshold: number of hours the instrument is turned ON, the controller is forced in stand-by when Co.ty value reaches the threshold set in [137] h.Job.         8 = Totalizer of control relay worked days: number of hours the control relay worked days: number of hours the control relay worked hours: number of hours the control relay worked hours: number of hours the control relay worked hours: number of hours the control relay worked days with threshold: number of hours the control relay worked days with threshold: number of hours the control relay worked days with threshold: number of hours the control relay worked days with threshold: number of hours the control relay worked days with threshold: number of hours the control relay worked days with threshold: number of hours the control relay worked days with threshold: number of hours the control relay has been in ON condition. </td <td><b>Default</b> oFF</td>	<b>Default</b> oFF
				threshold set in [137] h.Job. 11 = Totalizer of control relay worked hours with threshold: number of hours the control relay has been in ON condition, the controller is forced in stand-by when Co.ty value reaches the threshold set in [137] h.Job.	
С	138	t.Job	Worked time (not resettable)	0 9999 days	0

cAL	AL Group - User calibration group				
Liv	N°	Param	Description	Values	Default
С	139	AL.P	Adjust Low Point	From -1999 to (AH.P - 10) in engineering units	0
С	140	AL.o	Adjust Low Offset	-300 +300 (E.U.)	0
С	141	AH.P	Adjust High Point	From (AL.P + 10) to 9999 engineering units	999.9
С	142	AH.o	Adjust High Offset	-300 +300	0

## **OPERATIVE MODES**

When the instrument is powered, it starts immediately to work according to the parameters values loaded in its memory. The instrument behaviour and its performance are governed by the value of the stored parameters.

At power ON the instrument can start in one of the following mode depending on its configuration:

Automatic Mode In Automatic mode the instrument drives automatically the control output according to the parameter value set and the set point/measured value.

**Manual Mode** (OPLO): In Manual mode the the upper display shows the measured value while the lower display shows the power output [preceded by H (for heating) or C (for cooling)], MAN is lit and the instrument allows you to set manually the control output power. No Automatic action will be made.

**Stand by Mode** (St.bY): In stand-by mode the instrument operates as an indicator. It will show on the upper display the measured value and on the lower display the set point alternately to the "St.bY" messages and forces the control outputs to zero.

We define all the above described conditions as "Standard Display".

As we have seen, it is always possible to modify the value assigned to a parameter independently from the operative modes selected.

## AUTOMATIC MODE

Keyboard function when the instrument is in Auto mode:

	Modo Operatore
ſ	Allows entry into parameter modification procedures
	Allows you to start the "Direct set point modification" function (see below).
0	Allows you to display the "additional informations" (see below).
P	Performs the action programmed by [121] uSrb ( Perbutton function during RUN TIME) parameter

#### Additional information

This instrument is able to show you some additional informations that can help you to manage your system. The additional informations are related to how the instrument is programmed, hence in many cases, only part of this information is available.

- 1. When the instrument is showing the "standard display" push 🛆 button. The lower display will show H or c followed by a number. This value is the current power output applied to the process. The H show you that the action is a Heating action while the "c" show you that the action is a Cooling action
- 2. Push button again. When the programmer is running the lower display will show the segment currently performed and the Event status as shown below:

where the first character can be r for a ramp or S for a soak, the next digit show the number of the segment (e.g. S3 means Soak number 3) and the twoless significant digits (LSD) show you the status of the two event (the LSD is the Event 2)..

- 3. Push button again. When the programmer is running the lower display will show the theoretical remaining time to the end of the program preceded by a "P" letter:
  - <u> P843</u>
- 4. Push 🛆 button again. When the wattmeter function is running the lower display will show U followed by the measured energy..
- 5. Push button. When the "Worked time count" is running the lower display will show "d" for days or "h" for hours followed by the measured time.
- 6. Push 🛆 button. The instrument returns to the "standard display".

Note: The additional information visualization is subject to a time out. If no button is pressed for more than 10 second the instrument comes automatically back to the Standard display..

#### Direct set point modification

This function allows to modify rapidly the set point value selected by [83] A.SP (selection of the active Set point) or to the set point of the segment group (of the programmer) currently in progress.

- 1. Push **V** button. The upper display shows the acronym of the selected set point (e.g. SP2) and the lower display will show its value.
- 2. By  $\triangle$  and  $\nabla$  buttons, assign to this parameter the desired value
- 3. Do not push any button for more than 5 second or push the 🛃 button. In both cases the instrument memorize the new value and come back to the "standard display".

## Manual mode

This operative mode allows you to deactivate automatic control and manually program the percentage power output to the process. When the instrument is in manual mode, the upper display shows the measured value while the lower display shows the power output [preceded by H (for heating action) or C (for cooling action)] The MAN LED is lit. When manual control is selected, the instrument will start to operate with the same power output as the last one supplied by automatic mode and can be modified using the  $\triangle$  and  $\nabla$  buttons.

In case of ON/OFF control, 0% corresponds to the deactivated output while any value different from 0 corresponds to the activated output. As in the case of visualization, the programmable values range from H100 (100% output power with reverse action) to C100 (100% output power with direct action).

#### Notes:

- During manual mode, the alarms are operative.
- If you set manual modes during program execution, the program will be frozen and it will restart when the instrument will come back to Auto mode.
- If you set manual modes during self-tune execution, the self- tune function will be aborted.
- During manual mode, all functions not related with the control (wattmeter, independent timer, "worked time", etc) continue to operate normally..

## STAND-BY MODE

This operative mode also deactivates the automatic control but forces the control output to zero. In this mode the instrument operates as an indicator. When the instrument is in stand by mode the upper display will show the measured value while the lower display will show alternately the set point and the message "St.bY".

Notes:

- During stand by mode, the relative alarms are disabled while the absolute alarms are operative or not according to the ALxo (Alarm x enabling during Stand-by mode) parameter setting.
- If you set stand by mode during program execution, the program will be aborted.
- If you set stand by mode during self-tune execution, the self- tune function will be aborted.
- During stand by mode, all functions not related with the control (wattmeter, independent timer, "worked time", etc) continue to operate normally.
- When the instrument is swapped from stand by to auto modes, the instrument will start automatically the alarm masking, the soft start functions and the auto-tune (if programmed).

## AUTOTUNE (EVOTUNE)

Evotune is a fast and fully automatic procedure that can be started in any condition, regardless the deviation from SP. The controller selects automatically the best tune method and computes the optimum PID parameters. To activate Evotune press 😨 button for 3 seconds.

## **ERROR MESSAGES**

The upper display shows the OVER-RANGE and UNDERRANGE conditions with the following indications:

Over-range:

Under-range

The sensor break will be signalled as an out of range:

Note: When an over-range or an under-range is detected, the alarms operate as in presence of the maximum or the minimum measurable value respectively.

To check the out of span Error condition, proceed as follows:

- 1. Check the input signal source and the connecting line.
- 2. Make sure that the input signal is in accordance with the instrument configuration. Otherwise, modify the input configuration.
- 3. If no error is detected, send the instrument to your supplier to be checked.

## List of possible errors

**ErAT** Fast Auto-tune cannot start. The measure value is tooclose to the set point. Push the button in order to delete the error message.

**ouLd** Overload on the out 4. The messages shows that a short circuit is present on the Out 4 when it is used as output or as a transmitter power suply. When the short circuit disappears the output restart to operate..

NoAt Auto-tune not finished within 12 hours.

**ErEP** Possible problem of the instrument memory. The messages disappears automatically. When the error continues, send the instrument to your supplier.

RonE Possible problem of the firmware memory. When this error is detected, send the instrument to your supplier.

Errt Possible problem of the calibration memory. When this error is detected, send the instrument to your supplier.

## FACTORY RESET

Sometime, e.g. when you re-configure an instrument previously used for other works or from other people or when you have made too many errors during configuration and you decided to re-configure the instrument, it is possible to restore the factory configuration. This action allows to put the instrument in a defined condition (the same it was at the first power ON).

The default data are those typical values loaded in the instrument prior to ship it from factory. To load the factory default parameter set, proceed as follows:

- 1. Press the 🖵 button for more than 5 seconds. The upper display will show PASS while the lower display shows 0;
- 2. Using  $\triangle$  and  $\nabla$  buttons set the value -481;
- 3. Push 🗖 button;
- 4. The instrument will turn OFF all LEDs for a few seconds, then the upper display will show dFLt (default) and then all LEDs are turned ON for 2 seconds. At this point the instrument restarts as for a new power ON.

The procedure is complete.

Note: The complete list of the default parameters is available in Chapter "Configuration".

# RWF55.5X & RWF55.6X



User manual



Drilling dimensions:



2



#### NAVIGATION MENU



RWF55 is preset good for 90% of applications. However, you can set or edit parameters as follow:

## Set-point: set or modification:

When the burner is in stand-by, (safety loop open, that is terminals 3-4/T1-T2 on the 7 pole plug open) push the Enter button: on the lower display (green) Opr appears; push Enter again and in the same display SP1 appears. Push Enter again and the lower display (green SP1) flashes. Using the up and down arrows change the set-point on the upper display (red).Push Enter to confirm and push ESC more times to get the home position.

## PID parameters set and modifications (PArA):

Push Enter button, on the green display **Opr** appears; using the **down arrow**, scroll until group **PArA** is reached and push Enter. On the green display **Pb1** e appears and on the red one the set parameter. Push is sequence the **down or up** arrow the menu is scrolled. Push Enter to select and the **arrows** to choose the desired value. Enter to confirm

Parameter	Display	Range	Factory setting	Remarks
Proportional band	Pb1	1 9999 digit	10	Typical value for temperature
erivative action	dt	0 9999 sec.	80	Typical value for temperature
Integral action	rt	0 9999 sec.	350	Typical value for temperatureT
Dead band(*)	db	0… 999,9 digit	1	Typical value
Servocontrol running time	tt	10 3000 sec.	15	Set servocontrol running time
Switch-on differential(*)	HYS1	0,01999 digit	-5	Value under setpoint below which the burner switches back on (1N-1P closes)
Switch-off differential 2° stage (*)	HYS2	0,0 HYS3	3	(enable only with parameter bin1 = 4)
Upper switch-off differential (*)	HYS3	0,0 9999 digit	5	Value over setpoint above which the burner switches off (1N-1P opens)
Switch-on differential on cooling controller (*)	HYS4	0,0… 9999 digit	5	Do not used (enable only with parameter <b>CACt</b> = 0)
Switch-off differential 2° stage on cooling controller (*)	HYS5	HYS60,0 digit	5	Do not used (enable only with parameter <b>CACt</b> = 0 and parame- ter <b>bin1</b> =0)
Upper switch-off differential on cooling controller (*)	HYS6	0,01999 digit	5	Do not used (enable only with parameter CACt = 0)
Delay modulation	q	0,0 999,9 digit	0	Do not alter
T Outside temperature Curve point 1 (*)	At1	-40120 digit	-10	First point of external temperature for climatic curve
Boiler temperature Curve point 1 (*)	Ht1	SPLSPH	60	Set-point temperature for the external temperature 1
TT Outside temperature Curve point 2(*)	At2	-40120 digit	20	Second point of external temperature for climatic curve
Boiler temperature Curve point 2 (*)	Ht2	SPLSPH	50	Set-point temperature for the external temperature 2

(\*) Parameters affected by setting of decimal place (ConF > dISP parameter dECP)

#### Setting the kind of sensor to be connected to the device:

Push the **Enter** button: on the lower display (green) **Opr** appears. Using the **up and down arrows** find **ConF.** Push **Enter** to confirm. Now on the green display the group **InP** appears. Push **Enter** and **InP1** is displaied. Enter to confirm. You are inside **InP1**; the green display shows **Sen1** (sensor type), while the red display shows the chosen sensor code Push **Enter** to enter the **Sen1** parameter, then choose the desired sensor using the **arrows**. Push **Enter** to confirm and **ESC** to escape.

Once selected the sensor, you can modify all the other parameters using up and down arrows according to the tables here below :

#### ConF > InP >InP1

Parameter	Value	Description
SEn1	1	Pt100 3 wire
type of sensor for analog	2	Pt100 2 wire
input 1	3	Pt1000 3 wire
1	4	Pt1000 2 wire
	5	Ni1000 3 wire
	6	Ni1000 2 wire
	7	0 ÷ 135 ohm
	8	Cu-CuNi T
	9	Fe-CuNi J
	10	NiCr-Ni K
	11	NiCrSi-NiSi N
	12	Pt10Rh-Pt S
	13	Pt13Rh-Pt R
	14	Pt30Rh-Pt6Rh B
	15	0 ÷ 20mA
	16	4 ÷ 20mA
	17	0 ÷ 10V
	18	0 ÷ 5V
	19	1 ÷ 5V
OFF1	-1999 <b>0</b> +9999	Correction value measured by the sensor
Sensor offset		
SCL1	-1999 <b>0</b> +9999	minimum scale value(for input ohm, mA, V)
scale low level		
SCH1	-1999 <b>100</b> +9999	maximum scale value(for input ohm, mA, V)
scale high level		
dF1	0 <b>0,6</b> 100	Is used to adapt the digital 2nd order input filter (time in s; 0 s = filter off)
digital filter		
Unit	1	1 = <b>degrees</b> Celsius
	2	2 = degrees Fahrenheit
temperature unit		

## ConF > InP > InP2

Input 2 : this input can be used to specify an external setpoint or carry out setpoint shifting

Parameter	Value	Description
FnC2	0	0= no function
	1	1= external setpoint (display <b>SPE</b> )
	2	2 =setpoint shifting (display <b>dSP</b> )
	3	3 = angular positioning feedback
SEn2	1	0 ÷ 20mA
tisensor type input 2	2	4 ÷ 20mA
	3	0 ÷ 10V
	4	0 ÷ 5V
	5	1 ÷ 5V
	1	0 ÷ 20mA
OFF2	-1999 <b>0</b> +9999	Correction value measured by the sensor
Sensor offset		
SCL2	-1999 <b>0</b> +9999	minimum scale value(for input ohm, mA, V)
scale low level		
SCH2	-1999 <b>100</b> +9999	maximum scale value(for input ohm, mA, V)
scale high level		
dF2	0 <b>2</b> 100	Is used to adapt the digital 2nd order input filter (time in s; 0 s = filter off)
digital filter		

(**bold** = factory settings)

## ConF > InP >InP3

Input 3: this input is used to acquire the outside temperature

Parameter	Value	Description
SEn3	0	0 =
sensor type input 3sensor	1	1 = wire
type input 2	2	2 = wire
OFF3	-1999 <b>0</b> +9999	Correction value measured by the sensor
Sensor offset		
dF3	0 <b>1278</b> 1500	Is used to adapt the digital 2nd order input filter (time in s; 0 s = filter off)
digital filter		

## ConF > Cntr

Here, the type of controller, operating action, setpoint limits and presettings for self-optimization are selected

Parameter	Value	Description
CtYP	1	1 = 3-position controller (open-stop-close)
controller type	2	2 = continuative action controller (0 ÷10V or 4 ÷ 20mA)
CACt	1	1 = heating controller
control action	0	0 = cooling controller
SPL	-1999 <b>0</b> +9999	minimum set-point scale
least value of the set-point range		
SPH	-1999 <b>100</b> +999	maximum set-point scale
maximum value of the set- point range		
	0	0 = <b>Free</b>
Self-optimization	1	1 = Locked
		Self-optimization can only be disabled or enabled via the ACS411 setup program.
		Self-optimization is also disabled when the parameter level is locked
oLLo	<b>-1999</b> +9999	lower working range limit
set-point limitation start, operation limit low		
oLHi	-1999 <b>+9999</b>	upper working range limit
set-point limitation end, operation limit high		

(bold = factory settings)

## ConF > rAFC

Activation boiler shock termic protetion:

RWF55.. can activate the thermal shock protection only on sites where the set-point is lower than 250°C and according to **rAL** parameter

Parameter	Value	Description
FnCT		tchoose type of range degrees/time
type of contol	0	0 = deactived
	1	1 = Kelvin degrees/minute
	2	2 = Kelvin degrees/hour
rASL		Slope of thermal shock protection (only with functions 1 and 2)
ramp rate	<b>0,0</b> 999,9	
toLP	<b>2 x (HYS1) = 10</b> 9999	width of tolerance band (in K) about the set-point
tolerance band ramp		0 = tolerance band inactive
rAL ramp limit	<b>0</b> 250	Ramp limit. When this value is lower than the temperature set-point, the RWF controls the output increasing the temp set point step by step accor-
		ding to <b>rASL</b> . If this is over the temp set point, the control is performed in cooling

## Alarm functionAF

The alarm function can be used to monitor the analog inputs. If the limit value is exceeded, multifunctional relay K6 (terminals **6N** and **6P**) is activated (depending on the switching characteristic)

The alarm function can have different switching functions (lk1 to lk8) and can be set to a deviation from the active setpoint or to a fixed limit value

Limit value AL relative to setpoint (x)



Fixed limit value AL



## ConF > AF

Parameter	Value	Description
FnCt	0	0 = Without function
type of control	1	k1 = monitored input InP1
	2	lk2 = monitored input InP1
	3	k3 = monitored input InP1
	4	k4 = monitored input InP1
	5	k5 = monitored input InP1
	6	k6 = monitored input InP1
	/	k7 = monitored input InP1
	0 0	k8 = monitored input InP1
	9 10	lk7 = monitored input InP2
	10	lk8 = monitored input InP2
	12	lk7 = monitored input InP3
		lk8 = monitored input InP3
Alarm value	-1999	Limit value or deviation from setpoint to be monitored (see alarm functions
AL	0	<b>Ik1</b> to <b>Ik8</b> : limit value <b>AL</b> )
	1999	Limit value range for <b>lk1</b> and <b>lk2</b> 09999
HySt	0	Switching differential for limit value AL
switching differential	1	
	9999	
ACrA	0	Switched-off
response by out of range	1	ON
		Switching state in the case of measuring range overshoot or undershoot (Out of Range)

(bold = factory settings)

## ConF > OutP

For fuel-air ratio control purposes, the RWF55 has the binary outputs K2, K3 (terminals KQ,K2, K3) and the analog output (terminals A+, A-). The burner is released via relay K1 (terminals 1N, 1P).

The binary outputs of the RWF55 offer no setting choices

The RWF55 has an analog output.

The analog output offers the following setting choices:

Parameter	Value	Description
FnCt	1	1 = analog input 1 doubling with possibility to convert
type of control	2	2 = analog input 2 doubling with possibility to convert
	3	3 = analog input 3 doubling with possibility to convert
	4	4 = Controller's angular positioning is delivered (modulating controller)
SiGn		physical output signal (terminals A+, A-)
type of output signal	0	0 = 0÷20mA
	1	1 = 4÷20mA
	2	2 = 0÷10V DC
rOut	<b>0</b> 101	signal (in percent) when measurement range is crossed
value when out of input		
range		
oPnt	-1999 <b>0</b> +9999	A value range of the output variable is assigned to a physical output signal (for
zero point		FnCt = 1, 2, 3)
End	-1999 <b>100</b> +9999	A value range of the output variable is assigned to a physical output signal (for
end point		<b>FnCt =</b> 1, 2, 3)

## ConF > binF

This setting decides on the use of the binary inputs**D1**, **D2**, **DG** b

Parameter	Value	Description
bin1	0	0 = without function
binary imput 1 (terminals DG	1	1 = set-point changeover (SP1 / SP2)
– D1)	2	2 = lset-point shift (Opr > dSP parameter = value of set-point modify)
	3	β = input alarm
bin2	4	changeover of operating mode
binary imput 2 (terminalsκ		DG-D2 open = modulating operation
DG – D2)		DG-D2 close = 2 stage operation

(bold = factory settings)

## ConF > dISP

.Both displays can be customized to suit your needs by configuring the displayed value, decimal, time out and blocking

Parameter	Value	Description
diSU		Display value for upper display:
pper display (red)	0	0 = display power-off
	1	1 = analog input 1 (InP1) value
	2	2 = analog input 2 (InP2) value
	3	3 = analog input 3 (InP3) value
	4	4 = controller's angular positioning
	7	6 = set-point valueв
	,	7 = end value with thermal shock protection
diSL		Display value for lower display3:
lower display (green)	0	0 = display power-off
	1	1 = analog input 2 (InP2) value
	2	2 = analog input 2 (InP2) value
	3	3 = analog input 2 (InP2) value
	4 c	4 = controller's angular positioning
	<b>0</b> 7	6 = set-point valueв
	,	7 = end value with thermal shock protection
tout	0 <b>180</b> 250	time (s) on completion of which the controller returns automatically to the
timeout		basic display, if no button is pressed
dECP	0	0 = no decimal place
decimal point	1	1 = one decimal place
	2	2 = two decimal place
CodE	0	0 = no lockout
level lockout	1	1 = configuration level lockout (ConF)
	2	2 = parameter and configuration level lockout (PArA & ConF)
	3	3 = keyboard lockout

## ConF > IntF

The controller can be integrated into a data network using an optional RS-485 (terminals R+ and R-) interface or an optional Profibus DP interface(<u>only model</u>RWF55.6x\_terminalsC1-C2-C3-C4)

Parameter	Value	Description
bdrt	0	0 = 4800 baud
baudrate	1	1 = 9600 baud
	2	2 = 19200 baud
	3	3 = 38400 baud
Adr	0	Address in the data network
Device address Modbus	1	
	254	
dP	0 <b>125</b>	only withRWF55.6x
Device address Profibus		
dtt	0	0 = swiched-off
Remote detection time	30	
	7200s	

(**bold** = factory settings)

#### Manual control :

In order to manual change the burner load, while firing keep pushing the **ESC** button for more than 5 s; on the lower green display **Hand** appears.

using the **UP** and **DOWN** arrows, the load varies.

Keep pushing the **ESC** button for getting the normal operation again.

NB: every time the device shuts the burner down (start led switched off - contact 1N-1P open), the manual control is not active.

## Device self-setting (auto-tuning):

If the burner in the steady state does not respond properly to heat generator requests, you can activate the Device's self-setting function, which recalculates PID values for its operation, deciding which are most suitable for the specific kind of request

SIEMENS						
		2	5			
<del>П</del>		Ŀ				
	$\bigtriangledown$		С	<mark>K6</mark>	J	

Follow the below instructions:

push the **UP** and **DOWN** arrows for more than 5 s; on the green lower display **tUnE** appears. Now the device pushes the burner to increase and decrease its output. During this time, the device calculates **PID** parameters (**Pb1**, **dt** and **rt**). After the calculations, the **tUnE** is automatically deactivated and the device has already stored them.

In order to stop the Auto-tuning function while it works, push again the **UP** and **DOWN** arrows for more than 5 s. The calculated **PID** parameters can be manually modified following the previously described instructions.

## Display of software version :

The software version is shown by pushing Enter + UP arrow on the upper display.



#### Weather-compensated setpoint shifting(climatic regulation):

The RWF55 can be configured so that weather-compensated setpoint shifting is activated when an LG-Ni1000 outside sensor or a Pt1000 is connected (see parameter **InP3**).

To take into account the time response of a building, weather-compensated setpoint shifting uses the attenuated outside temperature rather than the current outside temperature

The minimum and maximum setpoints can be set using the lower setpoint limit **SPL** and the upper setpoint limit **SPH** of the menù **Crtr**. The system also prevents the lower working range limit **oLLo** and upper working range limit **oLHi** from exceeding/dropping below the system temperature limits.

The heating curve describes the relationship between the boiler temperature setpoint and the outside temperature. It is defined by 2 curve points. For 2 outside temperatures, the user defines the boiler temperature setpoint that is required in each case. The heating curve for the weather-compensated setpoint is calculated on this basis. The effective boiler temperature setpoint is limited by the upper setpoint limit **SPH** and the lower setpoint limit **SPL**.



For setting climatic regulation function set:

PArA > parametersAt1, Ht1, At2, Ht2

ConF > InP > InP3 parametersSEn3, FnC3 = 1 (Weather-compensated setpoint).

## Modbus interface

The tables that follow in this chapter specify the addresses of the readable and writable words that the customer is able to access. The customer may read and/or write the values using SCADA programs, PLCs, or similar.

The entries under Access have the following meanings:

 $\ensuremath{\textbf{R/O}}$  Read Only, value can only be read

R/W Read/Write, value can be read and written

The number of characters specified under Data type in the case of character strings includes the final \0.

Char10 means that the text is up to 9 characters long. The final \0 character is then added to this

### User level

Address	Access	Data type	Signal reference	Parameter
0x0000	R/O	Float	X1	Analog input InP1
0x0002	R/O	Float	X2	Analog input InP2
0x0004	R/O	Float	X3	Analog input InP2
0x0006	R/O	Float	WR	Actual setpoint
0x0008	R/W	Float	SP1	Setpoint 1
0x000A	R/W	Float	SP2 (= dSP)	Setpoint 2
0x1035	R/O	Float		Analog input InP3 (unfiltered)
0x1043	R/O	Float		Actual angular positioning
0x1058	R/O	Word	B1	Burner alarm

#### Parameter level

Address	Access	Data type	Signal reference	Parameter
0x3000	R/W	Float	Pb1	Proportional range 1
0x3004	R/W	Float	dt	Derivative action time
0x3006	R/W	Float	rt	Integral action time
0x300C	R/W	Float	db	Dead band
0x3012	R/W	Word	tt	Controlling element running time
0x3016	R/W	Float	HYS1	Switch-on threshold
0x3018	R/W	Float	HYS2	Switch-off threshold down
0x301A	R/W	Float	HYS3	Switch-off threshold up
0x301C	R/W	Float	HYS4	Switch-on threshold (cooling)
0x301E	R/W	Float	HYS5	Switch-off threshold down (cooling)
0x3020	R/W	Float	HYS6	Switch-off threshold up (cooling)
0x3022	R/W	Float	q	Reaction threshold
0x3080	R/W	Float	At1	Outside temperature 1
0x3082	R/W	Float	Ht2	Boiler temperature 1
0x3084	R/W	Float	At2	Outside temperature 2
0x3086	R/W	Float	Ht2	Boiler temperature 2

## **Configuration level**

Address	Access	Data type	Signal reference	Parameter
0x3426	R/W	Float	SCL1	Start of display input 1
0x3428	R/W	Float	SCH1	End of display input 1
0x3432	R/W	Float	SCL2	Start value input 2
0x3434	R/W	Float	SCH2	End value input 2
0x3486	R/W	Float	SPL	Start of setpoint limitation
0x3488	R/W	Float	SPH	End of setpoint limitation
0x342A	R/W	Float	OFFS1	Offset input E1
0x3436	R/W	Float	OFFS2	Offset input E2
0x343A	R/W	Float	OFFS3	Offset input E3
0x1063	R/W	Word	FnCt	Ramp function
0x1065	R/W	Float	rASL	Ramp slope
0x1067	R/W	Float	toLP	Tolerance band ramp
0x1069	R/W	Float	rAL	Limit value
0x1075	R/W	Float	dtt	Remote Detection Timer
0x1077	R/W	Float	dF1	Filter constant input 1
0x1079	R/W	Float	dF2	Filter constant input 2
0x107B	R/W	Float	dF3	Filter constant input 3
0x107D	R/O	Float	oLLo	Lower working range limit
0x107F	R/O	Float	oLHi	Upper working range limit
0x106D	R/W	Word	FnCt	Alarm relay function
0x106F	R/W	Float	AL	Alarm relay limit value (limit value alarm)
0x1071	R/W	Float	HYSt	Alarm relay hysteresis

## Remote operation

Address	Access	Data type	Signal reference	Parameter
0x0500	R/W	Word	REM	Activation remote operation *
0x0501	R/W	Word	rOFF	Controller OFF in remote setpoint **
0x0502	R/W	Float	rHYS1	Switch-on threshold remote
0x0504	R/W	Float	rHYS2	Switch-off threshold down remote
0x0506	R/W	Float	rHYS3	Switch-off threshold up remote
0x0508	R/W	Float	SPr	Setpoint remote
0x050A	R/W	Word	RK1	Burner release remote operation
0x050B	R/W	Word	RK2	Relay K2 remote operation
0x050C	R/W	Word	RK3	Relay K3 remote operation
0x050D	R/W	Word	RK6	Relay K6 remote operation
0x050E	R/W	Word	rStEP	Step-by-step control remote operation
0x050F	R/W	Float	rY	Angular positioning output remote operation
0x0511	R/W	Float	rHYS4	Switch-on threshold remote (cooling)
0x0513	R/W	Float	rHYS5	Switch-off threshold down remote (cooling)
0x0515	R/W	Float	rHYS6	Switch-off threshold up remote (cooling)

Legend

\* = Local

\*\* = Controller OFF

## Dati dell'apparecchio

Address	Access	Data type	Signal reference	Parameter
0x8000	R/O	Char12		Software version
0x8006	R/0	Char14		VdN number

## Stato dell'apparecchio

Address	Access	Data type	Signal reference	Parameter
0x0200	R/O	Word		Outputs and states
			Bit 0	Output 1
			Bit 1	Output 3
			Bit 2	Output 2
			Bit 3	Output 4
			Bit 8	Hysteresis limitation
			Bit 9	Control system
			Bit 10	Self-optimization
			Bit 11	Second setpoint
			Bit 12	Measuring range overshoot InP1
			Bit 13	Measuring range overshoot InP2
			Bit 14	Measuring range overshoot InP3
			Bit 15	Calibration mode
0x0201	R/O	Word		Binary signals and hardware detection
			Bit 0	Operation mode 2-stage
			Bit 1	Manual mode
			Bit 2	Binary input D1
			Bit 3	Binary input D2
			Bit 4	Thermostat function
			Bit 5	First controller output
			Bit 6	Second controller output
			Bit 7	Alarm relay
			Bit 13	Analog output available
			Bit 14	Interface available

#### **Electric connections :**



## Corrispondences bornes entre RWF55.5x y RWF40.0x0Matches terminals betweenRWF55.5x and RWF40.0x0

0	ка	SIEM K2 Ø	ENS   k3 Ø	RWF5 ™ Ø	5.5x 1P Ø	Ø	N Ø		13 Ø	G- ∅	G+ ∅	14 Ø	12 Ø	11 Ø	
	Q	SIEM Y1 Ø	ENS   y2 Ø	RWF4 a13 Ø	0.0xx Q14 Ø	L1	N Ø	pe Ø	U1	G-	G+ ∅	M1	VII Ø	G1+ ∅	

			Con	F			ConF								
Navigation menù	Inp														
	Inp1				Cı	Cntr diS		PArA						Opr	
Types of probe	SEn1	OFF1	SCL	SCH	Unit	SPL	SPH	dECP	Pb. 1	dt	rt	tt	HYS1 (*)	HYS3 (*)	SP1 (*)
Siemens QAE2120	6	0	needless	needless	1	30	95	1	10	80	350	(#)	-5	5	80 °C
Siemens QAM2120	6	0	needless	needless	1	0	80	1	10	80	350	(#)	-2,5	2,5	40°C
Pt1000 (130°C max.)	4	0	needless	needless	1	30	95	1	10	80	350	(#)	-5	5	80°C
Pt1000 (350°C max.)	4	0	needless	needless	1	0	350	1	10	80	350	(#)	-5	10	80°C
Pt100 (130°C max.)	1	0	needless	needless	1	0	95	1	10	80	350	(#)	-5	5	80°C
Pt100 (350°C max)	1	0	needless	needless	1	0	350	1	10	80	350	(#)	-5	10	80°C
Probe4÷20mA / 0÷1,6bar	16	0	0	160	needless	0	160	0	5	20	80	(#)	0	20	100 kPa
Probe4÷20mA / 0÷3bar	16	0	0	300	needless	0	300	0	5	20	80	(#)	0	20	200 kPa
Probe 4÷20mA / 0÷10bar	16	0	0	1000	needless	0	1000	0	5	20	80	(#)	0	50	600 kPa
Probe 4÷20mA / 0÷16bar	16	0	0	1600	needless	0	1600	0	5	20	80	(#)	0	80	600 kPa
Probe 4÷20mA / 0÷25bar	16	0	0	2500	needless	0	2500	0	5	20	80	(#)	0	125	600 kPa
Probe 4÷20mA / 0÷40bar	16	0	0	4000	needless	0	4000	0	5	20	80	(#)	0	200	600 kPa
Probe 4+20mA / 0+60PSI	16	0	0	600	needless	0	600	0	5	20	80	(#)	0	30	300 (30PSI)
Probe4÷20mA / 0÷200PSI	16	0	0	2000	needless	0	2000	0	5	20	80	(#)	0	75	600 (60PSI)
Probe4÷20mA / 0÷300PSI	16	0	0	3000	needless	0	3000	0	5	20	80	(#)	0	120	600 (60PSI)
Siemens QBE2002 P4	17	0	0	400	needless	0	400	0	5	20	80	(#)	0	20	200 kPa
Siemens QBE2002 P10	17	0	0	1000	needless	0	1000	0	5	20	80	(#)	0	50	600 kPa
Siemens QBE2002 P16	17	0	0	1600	needless	0	1600	0	5	20	80	(#)	0	80	600 kPa
Siemens QBE2002 P25	17	0	0	2500	needless	0	2500	0	5	20	80	(#)	0	125	600 kPa
Siemens QBE2002 P40	17	0	0	4000	needless	0	4000	0	5	20	80	(#)	0	200	600 kPa
Signal 0÷10V	17	0	needless	needless	needless	needless	needless	needless	5	20	80	(#)			
Signal 4÷20mA	16	0	needless	needless	needless	needless	needless	needless	5	20	80	(#)			

### Parameters summarising for RWF55.xx :

#### NOTE:

(#) tt - servo control run time

SQL33 ; STM30; SQM10; SQM40; SQM50; SQM54 = 30 (secondi) - STA12B3.41; SQN30.251; SQN72.4A4A20 = 12 (secondi) (\*)These values are factory set - values must be set during operation at the plant based on the real working temperature/pressure value.

#### WARNING :

With pressure probes in bar the parameters SP1, SCH, SCL, HYS1, HYS3 must be set and displayed in kPa (kilo Pascal); 1bar = 100,000Pa = 100kPa. With pressure probes in PSI the parameters SP1, SCH, SCL, HYS1, HYS3 must be set and displayed in PSI x10 (example: 150PSI > I display 1500).

#### APPENDIX: PROBES CONNECTION

To assure the utmost comfort, the control system needs reliable information, which can be obtained provided the sensors have been installed correctly. Sensors measure and transmit all variations encountered at their location.

Measurement is taken based on design features (time constant) and according to specific operating conditions. With wiring run in raceways, the sheath (or pipe) containing the wires must be plugged at the sensor's terminal board so that currents of air cannot affect the sensor's measurements.

#### Ambient probes (or ambient thermostats)

#### Installation

The sensors (or room thermostats) must be located in reference rooms in a position where they can take real temperature measurements without being affected by foreign factors.



#### It's good to be admired ...even better to be effective

Heating systems: the room sensor must not be installed in rooms with heating units complete with thermostatic valves. Avoid all sources of heat foreign to the system.





Outside probes (weather)Installation

In heating or air-conditioning systems featuring adjustment in response to outside temperature, the sensor's positioning is of paramount importance.





#### Location

On an inner wall on the other side of the room to heating unitsheight above floor 1.5 m, at least 1.5 m away from external sources of heat (or cold).



#### Installation position to be avoided

near shelving or alcoves and recesses, near doors or win-dows, inside outer walls exposed to solar radiation or currents of cold air, on inner walls with heating system pipes, domestic hot water pipes, or cooling system pipes running through them.



Avoid installing near windows, vents, outside the boiler room, on chimney breasts or where they are protected by balconies, cantilever roofs

The sensor must not be painted (measurement error) .

#### Duct or pipe sensors Installing temperature sensors

For measuring outlet air:

"after delivery fan or

"after coil to be controlled, at a distance of at least 0,5 m For measuring room temperature:

"before return air intake fan and near room's return airintake. For measuring saturation temperature: after mist eliminator.



#### Installing pressure sensors

- A installation on ducts carrying fluids at max. temperature 80°C
- B installation on ducts at temperature over 80°C and for refrigerants
- C installation on ducts at high temperatures :
  - · "increase length of siphon

"place sensor at side to prevent it being hit by hot air coming from the pipe.



Bend 0.4m sensor by hand (never use tools) as illustrated .



Use whole cross-section of duct, min. distance from walls 50 mm, radius of curvature 10 mm for 2m or 6m sensors

#### Installing combined humidity sensors

As max. humidity limit sensor on outlet (steam humidifiers) .



#### Installing differential pressure sensors for water

Installation with casing facing down not allowed.

With temperature over 80°C, siphons are needed.

To avoid damaging the sensor, you must comply with the following instructions :

when installing: make sure pressure difference is not greater than the value permitted by the sensor

when there are high static pressures, make sure you insert shutoff valves A-B-C.

#### Putting into operation

Start disable 1=open C1=open C 2=open A2=close B 3=open B3=close A 4= close C



#### Immersion or strap-on sensors



Placing the probes (QAD22.../QAE21.../QAP21.../RCA...)

With pumps on outlet

with 3 ways valves / with 4 ways valves



with 3 ways valves / with 4 ways valves





#### Immersion probes installation

Sensors must be installed on the stretch of pipe in which fluid circulates all the time.

The rigid stem (sensing element doing the measuring) must be inserted by at least 75mm and must face the direction of flow.

Recommended locations: on a bend or on a straight stretch of pipe but tilted by  $45^\circ$  and against the flow of fluid.

Protect them to prevent water from infiltrating (dripping gates, condensation from pipes etc.) .

#### Installing QAD2.. strap-on sensors

Make sure fluid is circulating in the chosen location. Eliminate insulation and paintwork (including rust inhibitor) on a min. 100mm length of pipe.

Sensors come with straps for pipes up to 100 mm in diameter .

# Strap-on or immersion sensors? QAD2.. strap-on sensors

Advantages :

- 10 sec. time constant
- Installed with system running (no plumbing work)
- Installation can be changed easily if it proves incorrect
- ΠLimits:
- Suitable for pipe diameters max. 100 mm
- Can be affected by currents of air etc.

#### QAE2... immersion sensors

Advantages:

- Measure "mean" fluid temperature
- No external influence on measurement such as: currents of air, nearby pipes etc.

Limits:

- Time constant with sheath: 20 sec.
- Hard to change installation position if it proves incorrect

#### Duct pressure switches and sensors

#### Installing differential pressure probes for air



A - Control a filter (clogging)



B - Control a fan (upstream/downstream)



C - Measurement of difference in pressure between two ducts



D - Measurement of difference in pressure between two rooms or of inside of duct and outside

# Basic principles

Measuring static pressure(i.e. pressure exerted by air on pipe walls)







#### Legend

- y Kg/m3, specific weight of air
- q m/s, air speed
- g 9.81 m/s2 gravity acceleration
- Pd mm C.A., dynamic pressure

Measuring total pressure



Note: Specifications and data subject to change. Errors and omissions excepted.









ata IS	3/10/2010	_	
Revisione 0	5	3	4
		SEGUE	TOTALE
Dis. N. <b>18</b>	- 0163	5	5

Sigla/Item	Funzione	Function				
600V RRR0-1-T73	REGOLATORE MODULANTE (ALTERNATIVO)	BURNER MODULATOR (ALTERNATIVE)				
C1 (1	CONTAORE BASSA FIAMMA	LOW FLAME TIME COUNTER				
[2	CONTAORE ALTA FIAMMA	HIGH FLAME TIME COUNTER				
ER	ELETTRODO RILEVAZIONE FIAMMA	FLAME DETECTION ELECTRODE				
EV1,2	ELETTROVALVOLE GAS (O GRUPPO VALVOLE)	GAS ELECTRO-VALVES (OR VALVES GROUP)				
FU1	FUSIBILE LINEA MOTORE VENTILATORE	FAN MOTOR LINE FUSE				
FU2	FUSIBILE DI LINEA	LINE FUSE				
FU3	FUSIBILE DI LINEA	LINE FUSE				
FU4	FUSIBILE AUSILIARIO	AUXILIARY FUSE				
IL	INTERRUTTORE LINEA BRUCIATORE	BURNER LINE SWITCH				
ĪM	INTERRUTTORE LINEA MOTORE VENTILATORE	FAN MOTOR LINE SWITCH				
KM1.1	CONTATTORE MOTORE VENTILATORE	FAN MOTOR CONTACTOR				
KM3 HCRMMD	REGOLATORE MODULANTE (ALTERNATIVO)	BURNER MODULATOR (ALTERNATIVE)				
LAF	LAMPADA SEGNALAZIONE ALTA FIAMMA BRUCIATORE	BURNER IN HIGH FLAME INDICATOR LIGHT				
LAF1	LAMPADA SEGNALAZIONE ALTA FIAMMA BRUCIATORE	BURNER IN HIGH FLAME INDICATOR LIGHT				
LB	LAMPADA SEGNALAZIONE BLOCCO BRUCIATORE	INDICATOR LIGHT FOR BURNER LOCK-OUT				
LB1	LAMPADA SEGNALAZIONE BLOCCO BRUCIATORE	INDICATOR LIGHT FOR BURNER LOCK-OUT				
LBF	LAMPADA SEGNALAZIONE BASSA FIAMMA BRUCIATORE	BURNER IN LOW FLAME INDICATOR LIGHT				
LBF1	LAMPADA SEGNALAZIONE BASSA FIAMMA BRUCIATORE	BURNER IN LOW FLAME INDICATOR LIGHT				
LEV1	LAMPADA SEGNALAZIONE APERTURA [EV1]	INDICATOR LIGHT FOR OPENING OF ELECTRO-VALVE [EV1]				
LEV2	LAMPADA SEGNALAZIONE APERTURA [EV2]	INDICATOR LIGHT FOR OPENING OF ELECTRO-VALVE [EV2]				
(I F	I AMPADA SEGNALAZIONE FUNZIONAMENTO BRUCIATORE	INDICATOR LIGHT BURNER OPERATION				
ilpg	LAMPADA SEGNALAZIONE PRESENZA GAS IN RETE	INDICATOR LIGHT FOR PRESENCE OF GAS IN THE NETWORK				
Ú.TA	I AMPADA SEGNALAZIONE TRASFORMATORE DI ACCENSIONE	IGNITION TRANSFORMER INDICATOR LIGHT				
MV	MOTORE VENTILATORE	FAN MOTOR				
ΡΑ	PRESSOSTATO ARIA	AIR PRESSURE SWITCH	$\neg$			
PG	PRESSOSTATO GAS DI MINIMA PRESSIONE	MINIMUM GAS PRESSURE SWITCH				
195 (PS		FI AME LINI OCK BUTTON				
PT100	SONDA DI TEMPERATURA	TFMPFRATURE PROBE				
IRC						
(SD-PRESS	SONDA DI PRESSIONE	PRESSURE PROBE				
SD-TEMP.	SONDA DI TEMPERATURA	TEMPERATURE PROBE				
SD - 0÷10V	TRASDUTTORF USCITA IN TENSIONE	TRANSDUCER VOLTAGE OUTPUT				
SD - 4÷20mA	TRASDUTTORE USCITA IN CORRENTE	TRANSDUCER CURRENT OUTPUT				
SIEMENS LGB2x.330/LME2x.33x	APPARECCHIATURA CONTROLLO FIAMMA	CONTROL BOX				
SIEMENS LME22.331	APPARECCHIATURA CONTROLLO FIAMMA					
SIFMENS RWF50.2x	REGOLATORE MODULANTE	BURNER MODULATOR				
SIEMENS RWF55.5x	REGOLATORE MODULIANTE (ALTERNATIVO)	BURNER MODULATOR (ALTERNATIVE)				
SIEMENS SQN72.4A4A20	SERVOCOMANDO SERRANDA ARIA (ALTERNATIVO)	AIR DAMPER ACTUATOR (ALTERNATIVE)				
ISMA	SELEVECTIONE MANUAL F/AUTOMATICO					
ISME	SELECTORE MANUAL FEINZIONAMENTO MIN-0-MAX	MIN_0_MAX MANUAL OPERATION SWITCH				
 ICT		SERIES OF THERMOSTATS OR PRESSURE SWITCHES				
 IST∆13B0 36/83N30L	SERVE LENNOS RAMA ALOSSO					
ΤΔ						
			$ \longrightarrow $			
тсі Гтс						
	TERMUSTATU/FRESSUSTATU DI SICUREZZA	SALETT THERPOSTAT ON TRESSORE SWITCH				

Data	19/10/2010	PREC.	FOGLIO
Revisione	05	4	5
		SEGUE	TOTALE
Dis. N. <b>1</b>	8 - 0163	1	5